GT4363

Electric Water Gun

with LED Nozzle & Recoil



INSTRUCTION MANUAL

SAFETY INFORMATION

Read these safety instructions carefully before using the product. Keep this manual for future reference.

WARNINGS

- Do not aim the water gun at the eyes or face.
- Not suitable for children under 3 years, small parts may present a choking hazard.
- Recommended for children aged 6 years and over.
- Adult supervision is required during operation and charging.
- Remove all packaging materials before giving the toy to a child and dispose of the materials safely.
- Do not modify or attempt to repair the water gun.
- Do not use the water gun if any component is damaged or loose.
- Keep the water gun away from heat or excessive moisture.
- Do not submerge the water gun in water to prevent damage.

Operation & Care:

- Securely close the battery compartment before use.
- Store the product in a cool, dry location away from direct sunlight.
- Always use clean fresh water only when filling the water tank, do not add soap or detergent.
- Do not fill the water tank with hot water, salt water or flammable liquids.
- Keep water away from the USB charging port.
- Clean the product using a soft, dry cloth.
- Do not use water, solvents or abrasive cleaners.
- Rinse the water tank with clean water and allow it to dry before storage.
- Always empty the water tank and allow it to dry before storage.

Battery Charging & Safety:

- The rechargeable battery must only be charged by an adult or under direct adult supervision.
- Only use the supplied USB charging cable.
- Connect the charging cable to a suitable 5V USB power source.
- Do not use a damaged charging cable, battery or USB power source.
- Charge the product indoors in a dry, well-ventilated location.
- Place the product on a hard, flat and non-flammable surface while charging.
- Do not leave the product unattended while charging.
- Do not charge the product overnight.
- Disconnect the charging cable when charging is complete.
- Do not operate the water gun while it is charging.
- Do not cover the water gun or charging cable during charging.
- Keep the product away from fire, direct sunlight and excessive heat.

PACKAGE CONTENTS

1 × Electric Water Machine Gun
1 × Rechargeable Battery Pack
1 × USB-C Charging Cable

FEATURES

- Shoots water up to 6 m
- Simulated recoil effects
- LED nozzle
- Rechargeable battery
- Includes USB charging cable

CHARGING THE BATTERY

1. Turn off the water gun.
2. Remove the battery pack from the battery compartment.
3. Connect the battery pack to the supplied USB-C charging cable.
4. Connect the cable to a suitable USB power source.
5. Charge for up to 3 hours.
6. Disconnect the battery once charging is complete and reinstall it securely before use.

FILLING THE WATER TANK

1. Lift up the water tank cap.
2. Fill the tank with clean tap water only.
3. Reattach the tank cap securely before use.
4. Always use clean water to help prevent the nozzles from becoming blocked.

HOW TO USE

1. Ensure the battery pack is charged and correctly installed.
2. Fill and attach the water tank.
3. Pull the trigger to spray water. The barrel and stock move together to create a simulated recoil effect.
4. Release the trigger to stop spraying.

SPECIFICATIONS

Water Capacity: 515ml
Play Time: Up to 40 Minutes
Charging Time: Up to 3 Hours
Battery: 3.7V Li-ion, 1200mA
Dimensions: 535(L) x 60(W) x 250(H)mm

WARRANTY INFORMATION

Our product is guaranteed to be free from manufacturing defects for a period of 12 Months.

If your product becomes defective during this period, Electus Distribution will repair, replace, or refund where a product is faulty; or not fit for intended purpose.

This warranty will not cover modified product; misuse or abuse of the product contrary to user instructions or packaging label; change of mind and normal wear and tear.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and failure does not amount to a major failure.

To claim warranty, please contact the place of purchase. You will need to show receipt or other proof of purchase. Additional information may be required to process your claim.

Any expenses relating to the return of your product to the store will normally have to be paid by you.

The benefits to the customer given by this warranty are in addition to other rights and remedies of the Australian Consumer Law in relation to the goods or services to which this warranty relates.

This warranty is provided by:

Electus Distribution
Address 46 Eastern Creek Drive, Eastern Creek NSW 2766
Ph. 1300 738 555