3+
AGES

GT4364

# Automatic Bubble Fountain Machine




# INSTRUCTION MANUAL

## WARNINGS

- Not suitable for children under 3 years, small parts may present a choking hazard.
- Recommended for children aged 3 years and over.
- Adult supervision is required during operation.
- Do not put your fingers in the top of the bubble fountain while moving as it may cause injury.
- Remove all packaging materials before giving the toy to a child and dispose of the materials safely.
- Do not modify or attempt to repair the bubble fountain.
- Do not use the bubble fountain if any component is damaged or loose.
- Keep the bubble fountain away from heat or excessive moisture.

**Operation & Storage:**

- Only use bubble solution in the fountain, do not put any other chemicals in such as detergent.
- Switch off the bubble fountain when not in use.
- Securely close the battery compartment before use.
- Store the product in a cool, dry location away from direct sunlight.
- Clean the product using a soft, dry cloth.
- Do not use water, solvents or abrasive cleaners.

**Battery Safety:**

- Keep the product away from fire, direct sunlight and excessive heat.
- Do not crush, puncture, bend, open, short-circuit or incinerate the batteries.
- Do not expose the battery to water or other liquids.
- Do not mix old and new batteries.
- Do not mix alkaline, standard carbon-zinc or rechargeable batteries.
- Do not mix batteries of different brands or capacities.
- Do not attempt to recharge non-rechargeable batteries.
- Remove exhausted batteries immediately.
- Do not short-circuit the battery terminals.
- Do not dispose of batteries in fire.
- Keep new and used batteries away from young children.

## PACKAGE CONTENTS

1 × Space Bubbles Bubble Machine
1 × 100 mL Bubble Liquid

## INSTALLING BATTERIES

1. Make sure the bubble machine is switched off.
2. Open the battery compartment using a screwdriver.
3. Insert 4 × AA batteries (not included), following the polarity markings inside the compartment.
4. Refit the battery cover securely before use.

## HOW TO USE

1. Place the bubble machine on a flat, stable surface.
2. Pour bubble liquid carefully into the bubble tray. Do not overfill.
3. Select the desired mode using the mode switch:
- Mode 1: Bubble function
- Mode 2: Bubble function with sound effects and LED lights
4. The machine will begin producing bubbles.

## WARRANTY INFORMATION

Our product is guaranteed to be free from manufacturing defects for a period of 12 Months.

If your product becomes defective during this period, Electus Distribution will repair, replace, or refund where a product is faulty; or not fit for intended purpose.

This warranty will not cover modified product; misuse or abuse of the product contrary to user instructions or packaging label; change of mind and normal wear and tear.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and failure does not amount to a major failure.

To claim warranty, please contact the place of purchase. You will need to show receipt or other proof of purchase. Additional information may be required to process your claim.

Any expenses relating to the return of your product to the store will normally have to be paid by you.

The benefits to the customer given by this warranty are in addition to other rights and remedies of the Australian Consumer Law in relation to the goods or services to which this warranty relates.

This warranty is provided by:

Electus Distribution
Address 46 Eastern Creek Drive, Eastern Creek NSW 2766
Ph. 1300 738 555