GT4365

Electric Water Gun with LED Pulse



INSTRUCTION MANUAL

SAFETY INFORMATION

Read these safety instructions carefully before using the product. Keep this manual for future reference.

WARNINGS

- Do not aim the water gun at the eyes or face.
- Not suitable for children under 3 years, small parts may present a choking hazard.
- Recommended for children aged 6 years and over.
- Adult supervision is required during operation and charging.
- Remove all packaging materials before giving the toy to a child and dispose of the materials safely.
- Do not modify or attempt to repair the water gun.
- Do not use the water gun if any component is damaged or loose.
- Keep the water gun away from heat or excessive moisture.
- Do not submerge the water gun in water to prevent damage.

Operation & Care:

- Securely close the battery compartment before use.
- Store the product in a cool, dry location away from direct sunlight.
- Always use clean fresh water only when filling the water tank, do not add soap or detergent.
- Do not fill the water tank with hot water, salt water or flammable liquids.
- Keep water away from the USB charging port.
- Clean the product using a soft, dry cloth.
- Do not use water, solvents or abrasive cleaners.
- Rinse the water tank with clean water and allow it to dry before storage.
- Always empty the water tank and allow it to dry before storage.

Battery Charging & Safety:

- The rechargeable battery must only be charged by an adult or under direct adult supervision.
- Only use the supplied USB charging cable.
- Connect the charging cable to a suitable 5V USB power source.
- Do not use a damaged charging cable, battery or USB power source.
- Charge the product indoors in a dry, well-ventilated location.
- Place the product on a hard, flat and non-flammable surface while charging.
- Do not leave the product unattended while charging.
- Do not charge the product overnight.
- Disconnect the charging cable when charging is complete.
- Do not operate the water gun while it is charging.

- Do not cover the water gun or charging cable during charging.
- Keep the product away from fire, direct sunlight and excessive heat.

PACKAGE CONTENTS

1 × Electric Water Gun
1 × USB Charging Cable
1 × Rechargeable 3.7V Li-ion Battery

CHARGING THE BATTERY

1. Switch off the water gun.
2. Open the battery compartment and remove the rechargeable battery.
3. Connect the battery to the USB charging cable.
4. Connect the cable to a suitable USB power source.
5. Disconnect the battery from the cable once charging is complete.
6. Reinstall the battery securely before use.

FILLING THE WATER GUN

Automatic Water Absorption

1. Ensure the rechargeable battery is installed.
2. Place the nozzle into clean water.
3. Push the trigger forwards to suck water into the nozzle.
4. The water gun will draw water into the internal tank.
5. After filling, lift the nozzle out of the water to drain any remaining water from the nozzle.

Manual Filling

1. Open the top cover of the water tank.
2. Fill the tank with clean tap water.
3. Close the cover securely before use.

Note: Only fill the water gun with clean, fresh water otherwise it may damage the water gun.

HOW TO USE

1. Fill the water gun using either automatic water absorption or the manual filling method.
2. Press the trigger to fire water continuously.
3. The LED pulse lights operate during use.
4. Release the trigger to stop firing.

SPECIFICATIONS

Water Capacity:	990ml
Play Time:	Up to 40 Minutes
Charging Time:	Up to 3 Hours
Battery:	3.7V Li-ion, 1200mA
Dimensions:	565(L) x 55(W) x 205(H)mm

WARRANTY INFORMATION

Our product is guaranteed to be free from manufacturing defects for a period of 12 Months.

If your product becomes defective during this period, Electus Distribution will repair, replace, or refund where a product is faulty; or not fit for intended purpose.

This warranty will not cover modified product; misuse or abuse of the product contrary to user instructions or packaging label; change of mind and normal wear and tear.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and failure does not amount to a major failure.

To claim warranty, please contact the place of purchase. You will need to show receipt or other proof of purchase. Additional information may be required to process your claim.

Any expenses relating to the return of your product to the store will normally have to be paid by you.

The benefits to the customer given by this warranty are in addition to other rights and remedies of the Australian Consumer Law in relation to the goods or services to which this warranty relates.

This warranty is provided by:

Electus Distribution
Address 46 Eastern Creek Drive, Eastern Creek NSW 2766
Ph. 1300 738 555