Spare 2 Channel Key Fob Controller
LR8856 - User Guide

Pair for use with LR8855:

- Press the "Learn" button on the LR8855 PCB, then press number 1 on the remote control 3 times.

- Press any button on the remote control again, the LED near the "Learn" button should light up when pressed, this confirms the pairing process was successful.