

# digitech

## Wireless TWS Earphones with Bluetooth® 5.3 Technology



**User Manual**  
AA-2165

## Box Contents:




2 x TWS Earphones 1 x USB Charging Case



1 x USB Micro B Charging Cable

## Product Diagram:



#	Feature	Description
1.	Play/Pause / Call/Volume Button	Press to play or pause while playing music Press to accept, reject or redial last number called
2.	Microphone/LED Status Indicator	Microphone located in the right and left earphones for phone calls Display the power and pairing status

3.	LED Status Indicator	Displays the power and pairing status of the earphones
4.	Speaker	Earphone speaker covered by a dustproof mesh
5.	Speaker	Earphone speaker covered by a dustproof mesh



	Feature	Description
1.	USB Power Socket (Rear)	Connect to the USB charging cable and suitable USB power source
2.	Charging Ports	Charges the earphones
3.	Earphone Case LED Battery Indicator	Displays the current battery status of the earphone case

## Operation:

### Bluetooth Pairing:

1. Make sure the earphones are fully charged before use, pull both earphones out of the charging case.

**Note: Press and hold the power button for up to 5 seconds to turn the earphones off.**

2. The LED indicator should be flashing red and blue. Open the settings of your smart phone and ensure Bluetooth® is turned on.

3. Once your Bluetooth® is enabled; Scan for devices and the Bluetooth® name AA-2165 should appear.

Bluetooth® Name: **AA-2165**

4. Press the AA-2165 on the Bluetooth® device list and your smartphone should show that it is connected.

5. You will hear a voice prompt from the earphones saying “Connected”. The volume can be controlled by your smartphone or earphones. The battery status can also be shown in your Bluetooth settings.

**Note: The earphones will automatically turn off after 3 minutes or if they’re too far away from your device.**

## **Bluetooth® Hands-Free:**

<b>Function</b>	<b>Button</b>
Answer Incoming Call	Press the play/call button to answer the current incoming call
Reject Incoming Call	Press the play/call button two times to reject the current incoming call
Hang Up Call	Once a call has been received; press the play/call button again to hang up
Google Assistant & Siri®	Press the play/call for up to 1.5 seconds to activate Google Assistant or Siri® on your smartphone. Your smartphone or tablet requires Google Assistant or Siri in order to work

## Music Playback:

Function	Button
Pause	Press the play/call button t to pause the current music track
Play	Press the play/pause button again after pausing to resume the current music track
Next Track	Press the play / call button 2 times to skip to the next music track
Volume	Press the play / call button 3 times to turn the volume up or down

## Charging:

### Earphones:

Insert the earphones into the earphone charging case to recharge them. The red LED should now be lit on the earphones to indicate charging.

**Note:** The LED indicator will turn off once the charging has finished.

## Charging Case:

1. Insert the USB micro B charging cable in a 5VDC mains power adaptor (not included) or a suitable USB charging port such as a computer.
2. Insert the micro B USB plug into the USB power socket of the charging case.
3. The LED status indicator will flash blue once charging has started.
4. Once fully charged; the LED status indicator will turn to a solid blue.

## Troubleshooting:

<b>Problem:</b>	<b>Solution:</b>
Battery Won't Charge Or Power On	Connect to a suitable USB charging source such as a USB mains power adaptor or USB charging port and make sure it's correctly turned on.
	Make sure the battery is fully charged up to 2 hours and make sure the LED status indicator has turned off.

<b>Problem:</b>	<b>Solution:</b>
No Power / LED Indicator	Ensure the USB charging cable is connected properly to a USB charging port or USB charging adaptor.
	Check to see if your USB power source is working correctly.
No Audio	Ensure the volume is correctly turned up on your smartphone.
	Ensure the earphones are correctly paired and turned on.
	Turn the earphones off and on again, turn off the Bluetooth of your smartphone or tablet and turn back on.
	Type in the password "0000" if it asks you for one.

## **Safety:**

1. Do not open the earphones or charging case of this product to prevent the unit from damage.
2. Keep the earphones and earphone charging case away from high temperatures as it may damage the device.
3. Do not expose the earphones or earphone charging case to water or liquids to prevent the unit from damage.

## Specifications:

Bluetooth® Version: 5.3+EDR

Transmission Range: Up to 10m

Frequency Response: 20Hz-20KHz

Sensitivity: 95dB±3dB

Mic Sensitivity: -42dB±3dB

Impedance: 32Ω

Driver Size: 10mm

Playback Time: 2-4 Hours

Talk Time: Up to 4 Hours

Standby Time: Up to 100 Hours (Single)

Up to 60 Hours (Both)

Charging Time: Up to 1 Hour (Earphones)

Up to 2 Hours (Charging Case)

Battery: 3.7V Li-Ion, 30mA (Each Earphone)

3.7V Li-ion, 300mA (Battery Case)

Power: 5VDC, 500mA (Micro B USB)

Power Consumption: 10mA Each (Max)

Dimensions:

41(H) x 18(W) x 17(D)mm (Each Earphone)

68(L) x 45(W) x 22(D)mm (Case)

Distributed by:  
Electus Distribution Pty. Ltd.  
46 Eastern Creek Drive, Eastern Creek  
NSW 2766 Australia  
Ph: 1300 738 555  
Int'l: +61 2 8832 3200  
Fax: 1300 738 500  
[www.electusdistribution.com.au](http://www.electusdistribution.com.au)