



CIRCUIT TRUE WIRELESS EARBUDS

AEP-0692-BLACK / AEP-0692-BLUE / AEP-0692-PINK




Instruction Manual

Product Overview

Circuit True Wireless Earbuds

Portable Charging Case



Remove the protective stickers before using

1. Touch Control On / Off Button / Play / Pause Music / Answer / End Call
2. LED Indicator
3. Built-in Microphone
4. IPX4 Water Protection Earbuds
5. Charging Case Battery Level Indicator
6. Earbuds Battery Level Indicator
7. USB Type-C Charging Port

Package Contents

- Includes:
- 1(One) Pair Earbuds 1.7in. x 1.5in. x 1.0in. (4.4cm x 3.7cm x 2.6cm) each
 - 1(One) Portable Charging Case 3.3in. x 2.3in. x 1.3in. (8.4cm x 5.8cm x 3.2cm)
 - 1(One) USB-C Charging Cable 11.8in. (30cm)
 - 1(One) Instruction Manual

Specifications

Driver Diameter: 10 mm
 Impedance: 32 Ohms
 Frequency Response: 20 Hz - 20 kHz
 Sensitivity: 96 dB +/- 3 dB
 Power Supply: Li-ion Battery 3.7V 35 mAh Per Earbud
 Charging Time: 2 Hours
 Bluetooth Range: 10 Metres
 Bluetooth Version: 5.3
 Charging Case Battery Capacity: 300 mAh
 USB Type-C Charging Cable Included (USB Type-C Charging Cable Rating 5V/1A Max.)

Power On/Off

Power On
 Press and hold down the ON/OFF Button of earbuds for 3 seconds and the LED will flash.

Power Off
 Press and hold down the ON/OFF Button of earbuds for 4 seconds and the LED will turn off.

Pair the wireless earbuds with your mobile device

Note: If there are protective stickers on the earbuds, remove these before use. Store the earbuds in the charging case for charging when not in use.

1. Keep the earbuds close to your mobile device (within 10 metres).
2. Turn off Bluetooth function on your mobile device.
3. Remove the earbuds from the charging case and wait for a few seconds; the earbuds will enter pairing mode. The indicator on one earbud blinks white.
4. Turn on Bluetooth on your mobile device and select 'Awa AEP-0692' from the list of devices. Once pairing is successful, the indicator stops blinking.

If pairing is not successful

- Make sure the earbuds are charged. Check charging level by keeping the earbuds in the charging case.
- Turn off Bluetooth on your mobile device (as well as any other devices to which the earbuds were previously paired).
- Press and hold ON/OFF buttons on both earbuds simultaneously for 3 seconds. Then restart the pairing process as explained above.

Reconnect the wireless earbuds to your mobile device

When powered on, the wireless earbuds will automatically connect with the last successfully paired device.

Disconnect the wireless earbuds from your mobile device

Power off the wireless earbuds; or
 Switch off the Bluetooth on your mobile phone; or
 Leave the earbuds 10m away from your mobile phone or further.

Answer / Reject a call

When you receive a phone call, press the ON/OFF Button once (on either earbud) to accept the call, or answer the call normally via your mobile phone. Press and hold 2 seconds to reject it.

End a call

To end the call, press the ON/OFF button on either earbud until a beep sound will be heard.

Functions

Pause / play music: Short press ON/OFF button on either earbud.
 Play previous song: Double press ON/OFF button on the left earbud.
 Play next song: Double press ON/OFF button on the right earbud.
 Voice Assistant: Press and hold ON/OFF button for 2 seconds.

Charging your Earbuds

IMPORTANT: Remove any protective stickers on the earbuds before charging.

1. Open the Charging Case cover.
2. Remove any protective stickers between the earbuds and the charging case and place the earbuds in the charging case for charging.
3. When placed in the charging case, the earbuds will be charged automatically.
4. The LED indicators on the earbuds will turn on during charging and turn off when fully charged.

Note: If charging does not start, take out both earbuds from the charging case and replace it after a few seconds.

Recharge Charging Case

For your safety, please always use appropriate 5V output charger/Adapter to charge the product.

DO NOT USE Quick Charging USB Adapter to charge the product, as it might damage the product.

1. Use the USB Type-C charging cable provided with the packaging.
2. Connect the USB plug to a wall adapter, then connect the USB Type-C plug to the USB Type-C charging port on the charging case to begin charging.
3. The last digit of the Battery Level Indicator will be flashing during charging.
4. Once fully charged, the Battery Level Indicator will stop flashing.
5. The Earbuds Battery Level Display will be flashing when earbuds are charging and will be off after fully charged.

NOTE:

- Use a standard USB adaptor for charging.
- Charge the Charging Case and Earbuds if it has not been used for more than 6 months.



CAUTION: The USB Type-C charging cable included with this item is intended for use with this product. Only use the included USB Type-C charging cable to charge this product.

FAQ

If the wireless earbuds cannot be paired with your device, please try the following:
 Ensure that your earbuds are in pairing mode or reconnection mode
 Ensure that Bluetooth search function of your mobile device is activated.

If the wireless earbuds will not turn on:
 Make sure the earbuds are fully charged.
 Make sure the protective stickers are removed from the Earbuds

Can I change the battery for the earbuds and the charging case?

The wireless earbuds and the charging case use a built-in non-detachable battery which cannot be removed.

If the charging case cannot be recharged:
 If you use a power outlet, ensure that the power supply is connected securely and the outlet works.

⚠ Safety instructions for the lithium battery and charging the product

- The input voltage to the product is 5V 1A.
- In order to charge the product in safe manner and reliable conditions, please only adopt certified appropriate charger/ adapter for charging the product.
- Only charge the product at ambient temperatures between 10 °C/ 50 °F and 40 °C/ 104 °F.
- Do not throw into fire. Keep free from dust and away from liquids, heat sources or direct sunlight.
- Switch off the product after use.
- Use only as specified in these instructions. Incorrect usage may lead to injury or product damage.
- This product is not a toy! Children should be supervised to ensure that they do not play with the appliance.
- No user-serviceable parts inside. Do not dismantle.
- Do not immerse in liquids.
- In extreme cases, abuse or misuse of Lithium battery pack can lead to explosion, heat generation, fire development or smoke development.