

digitech

Bluetooth® 5.3

Wireless Headset

with Active Noise Cancellation



Model:
AA2240




R-NZ

Please read and save all instructions to ensure safe and effective use of this product.

Instruction Manual

1.0 Product description




2.0 Specifications

Speaker size	Φ40.0mm
Call duration	About 30 hours
Charging time	2 hours
Standby time	100 hours
Wireless version	V 5.3
Playtime (Wireless with ANC mode on)	38 hours
Playtime (Wireless with ANC mode off)	48 hours
Weight	236 g / 8.3 oz
Battery capacity	400mAh
Output	35mW
Transmission range	≥ 10m
Wireless frequency	2.401 - 2.480GHz
SNR	110Db

3.0 Key function guide

X1: Press once Hold: Press and hold

	X 1		Activate Siri Short press to wake up Siri
	Hold	ANC	Noise canceling mode Long press 2S to switch the headphones to active noise- canceling mode
	X 1		Next song Short press to switch to the next song
	Hold		Volume down Long press to decrease the volume
	Hold		On/Off button Press and hold the power button 3S to turn on, press and hold the power button 3S to turn off
	X 1		Play/Pause In music mode: Short press to switch between play/pause
	X 1		Answer/Hang up Short press on/off button to answer/hang up call
	Hold		Reject In phone mode: Long press 2S to reject the call
	X 1		Previous song Short press to switch to the previous song
	Hold		Volume up Long press to increase the volume

4.0 Indicator

	Steady green	Active noise canceling mode
	Rapidly flashing blue and red	Pairing mode
	Steady red	Charging status

5.0 Wireless pairing

Steps:

Turn on the headphones and enable Bluetooth on your mobile phone. Search for the "K0Y2" and connect to the headphones.



6.0 Charging

When the headphones are either powered on or powered off, plug in a Type-C charging cable, and the headphone power light will stay red while charging and turn off after fully charged.


(Note: Plugging in the charging cable while the headphones are powered on will result in the headphones automatically turning off.)

7.0 Aux audio cable

1. When the headphones are powered off, insert a 3.5mm AUX audio cable to play music from a phone or other player to experience Hi-Res sound quality.

2. When the headphones are powered on, inserting a 3.5mm AUX audio cable will automatically turn off the headphones.

(Note: Using this function while the headphones are charging is not recommended.)



8.0 Disclaimers

KY02 reserves the right of final interpretation of this manual and the design and specifications are subject to change without notice.

Warranty Information

Our product is guaranteed to be free from manufacturing defects for a period of 12 Months. If your product becomes defective during this period, Electus Distribution will repair, replace, or refund where a product is faulty; or not fit for intended purpose.

This warranty will not cover modified product; misuse or abuse of the product contrary to user instructions or packaging label; change of mind and normal wear and tear.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and failure does not amount to a major failure.

To claim warranty, please contact the place of purchase. You will need to show receipt or other proof of purchase. Additional information may be required to process your claim.

Any expenses relating to the return of your product to the store will normally have to be paid by you.

The benefits to the customer given by this warranty are in addition to other rights and remedies of the Australian Consumer Law in relation to the goods or services to which this warranty relates.

This warranty is provided by:

Electus Distribution

Address 46 Eastern Creek Drive, Eastern Creek NSW 2766

Ph. 1300 738 555