

# RAVE

**Bubble Machine**



**AB-1229**

**- User Manual -**

## **Box Contents**

- 1 x Bubble Machine
- 1 x Power cable
- 2 x Mounting screws

Thank you for purchasing the AB1229 Bubble Machine. Please carefully read the following details for safe & proper operations

## **CAUTION**

- This is NOT a toy! Children under the age of 12 years old must be supervised by an adult when operating the machine
- Do not stop the bubble wheel by force, this will damage the inside motor!
- Be particularly careful not to insert fingers etc. into the turning bubble wheel

## **OPERATION**

- Carefully unpack your Bubble Machine from the box
- Use the 2 supplied mounting screws to install the handle to the housing
- Put the unit on a flat & firm surface, then carefully fill Bubble Liquid into the front side tank
- For proper output, make sure that that bottom bubble wheel rings are completely covered with liquid
- Do not fill too much liquid into the tank – stop 5cm below tank top edge to avoid overflow & internal damage
- Only use proper **Bubble Liquid** – the machine CANNOT run with water only or other unqualified liquids!
- Connect the power cable to your mains socket
- Switch the machine on via the housing backside on/off switch. The bubble wheel will start turning & blowing bubbles
- When finished, disconnect power & remove all bubble liquid from the tank

## **TROUBLESHOOTING**

- If the Bubble Wheel doesn't turn, check that
  - The plug is properly connected to the mains socket & that the item is switched on
  - No packing materials or other parts are blocking the wheel movement
  - There is a fuse inside the fuse compartment & that the fuse is not blown. If the fuse is blown, replace with 1A 250V
- If the bubble wheel is turning but no bubbles coming out, check that there is enough liquid inside the tank & that you use original Bubble Liquid. The unit cannot operate with water or unqualified liquids
- If there are continuous problems contact your local customer service for support

## **TECHNICAL SPECIFICATIONS**

Power supply: 220-240V ~ 50Hz  
Power consumption: 20W  
Fuse: 1A 250V

Distributed by:  
TechBrands by Electus Distribution Pty.Ltd.  
NSW 2116 Australia  
Ph: 1300 738 555  
Int'l: +61 2 8832 3200  
Fax: 1300 738 500  
[www.techbrands.com](http://www.techbrands.com)