

• FAQ

Q: TV displays with black borders around the edge:

A:1) Adjust the display ratio with the mode switch button;

2) Set TV to full screen mode(full pixel display).

Q: the TV shows "No signal"

A:1) Please check whether there is a HDMI signal input;

2) Try to replace high quality or shorter HDMI cables

3) Try to reduce the resolution of signal source.

• SPECIFICATION

Item	Description
HDMI signal	HDMI1.3, Full compatible with HDCP1.2
Input port	1×HDMI
Output port	4×HDMI
Audio format	PCM
HDMI resolution	480i@60Hz, 480p@60Hz , 576i@50Hz , 576p@50Hz , 720P@50/60Hz,1080p@50/60Hz
Working temperature	0-60°C
Power supply	12V /2A
Power consumption	<10W
Product dimension	214(L)x108.6(W)x25.5(H)mm
Weight	610g
Color	Black

Disclaimer

The product name and brand name may be registered trademark of related manufactures. ™ and ® may be omitted on the user manual. The pictures in this user manual are just for reference. The terms HDMI, HDMI High-Definition Multimedia Interface, and the HDMI Logo are trademarks or registered trademarks of HDMI Licensing Administrator, Inc. We reserve the rights to make changes without further notice to a product or system described herein to improve reliability, function or design.

HDMI 2×2 Video Wall Controller

User Manual

