

RESPONSE

FM Transmitter with Wireless Technology



AR3141

Instruction Manual

INDEX

Description	3
Features	3
Box Contents.....	4
Product Diagram	4
Usage Instructions.....	5
Specifications	7
Warranty Information	8

DESCRIPTION

This device streams music and phone calls directly from your Bluetooth device to your car's FM stereo system. With built-in Bluetooth 5.3, it provides a smooth hands-free experience. It also includes multiple fast-charging ports (PD 30W + QC3.0, total 48W) to quickly charge your devices. The dedicated bass button enhances your listening experience with deeper sound.

FEATURES


- Streams music and calls to your car's FM stereo via Bluetooth 5.3
- Hands-free calling for safer driving
- One-touch Bass Boost button
- Dual fast-charging ports: PD 30W + QC3.0 (48W total)
- Blue ring light for a stylish night drive
- Supports USB drives up to 32GB
- Quick access to Siri or Google Assistant

BOX CONTENTS

1x Wireless FM Transmitter

1x User Guide

PRODUCT DIAGRAM



1. USB music port
2. Microphone
3. PD30W charging port
4. LED display
5. QC3.0 charging port
6. Rotary multi-functions button
7. Bass booster button
8. Previous song / FM+
9. Next song / FM-
10. Auxiliary power plug

USAGE INSTRUCTIONS

Installing the product

Plug the auxiliary power plug (10) into an auxiliary power outlet. The LED display (4) shows the voltage of the battery of the car first for a few seconds and then shows "BT" to indicate Bluetooth pairing mode is activated.

Pair with Bluetooth

When LED display shows "BT" this indicates the unit is ready to pair.

1. Enable Bluetooth on the device you want to pair.
2. Search and select " AR3141 " from the list of available Bluetooth devices on your smartphone to pair and connect.
3. If asked, enter the pairing code '0000' or '1234'.

Connect to FM radio

When the Bluetooth has successfully connected from your device, the LED Display will show the FM frequency, try to select a frequency that is not occupied by a radio station to avoid signal disturbance.

1. Tune your car radio to an unused FM frequency
2. Press and hold the multifunction button (6) on the FM transmitter for 2 seconds until the frequency display (4) starts blinking.
3. You can now rotate clockwise or anticlockwise the rotary multifunction button (6) to increase or decrease the frequency adjustment to be the same as your car radio. This can also be done by pressing the (8) and (9) buttons to tune up or down accordingly.

Playing music

To stream music from the product to the FM radio, choose one of the following options:

- Play music directly from the mobile device that is connected to the product via Bluetooth.
- Insert a USB flash drive (not included) into the (1) USB music port, it will be played automatically.

Controlling the music

- Press the button (6) to play or pause music.
- Press the button (8) to go back to the previous song.
- Press the button (9) to skip to the next song.
- Rotate the button (6) in clockwise to increase the volume.
- Rotate the button (6) anticlockwise to decrease the volume.
- Press the bass booster button (7) to activate the bass boost.

If you receive a call while playing music, the product automatically switches to the phone call.

Making phone calls

- To answer an incoming call, press (6).
- During a call, press and hold (6) for 2 seconds to switch to private mode.
- To end a call, press (6).
- To ignore a call, press and hold (6) for 2 seconds.
- To quickly redial the last called number, double press (6).

Activating voice assistant

When in bluetooth mode, double press quickly (7) to activate voice assistant on your mobile phone (Siri or Google Assistant).

Charging mobile devices

When charging, connect your USB device with a USB cable (not included) to one of the two USB charging ports (USB & PD).

Voltage outputs:

PD30W 5V/3A 9V/3A 12V/2.5A

QC3.0 5V/3A 9V/2A 12V/1.5A

SPECIFICATIONS

Bluetooth version:	V5.3
Bluetooth Frequency Range:	2402-2480Mhz
FM frequency:	87.5-108.0MHZ
Frequency stability:	±10ppm
Product Input:	12-24V
LED display dimensions:	18 x 6 x 4mm
Charger output:	PD 30W+QC3.0 (total 48W)
USB Disk (Max capacity):	32GB
Music Format:	MP3\WMA\WAV\APE\FLAC
Bluetooth Distance:	About 5 m
Product Weight:	42g
Product Dimensions:	38.3 x 46.2 x 87.4mm
Material:	ABS

WARRANTY INFORMATION

Our product is guaranteed to be free from manufacturing defects for a period of 12 Months.

If your product becomes defective during this period, Electus Distribution will repair, replace, or refund where a product is faulty; or not fit for intended purpose.

This warranty will not cover modified product; misuse or abuse of the product contrary to user instructions or packaging label; change of mind and normal wear and tear.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and failure does not amount to a major failure.

To claim warranty, please contact the place of purchase. You will need to show receipt or other proof of purchase. Additional information may be required to process your claim.

Any expenses relating to the return of your product to the store will normally have to be paid by you.

The benefits to the customer given by this warranty are in addition to other rights and remedies of the Australian Consumer Law in relation to the goods or services to which this warranty relates.