

digitech

Audio/Bluetooth®

Handsfree Vehicle Kit

with PD 20W & QC3.0 total 38W Max



Model:
AR3146

Instruction Manual

Table of Contents

Introduction	3
Package Contents	3
Specifications	3
Features	4
Precautions	4
Operation Instructions	5
Song Selection	6
Using FM Transmitter Function	6
Using Bluetooth Function	6
Bluetooth Calling	6
Using USB Charger Function	7
Bass Button	7
How to Activate Voice Assistant (e.g. Siri/Google assistant)	7

INTRODUCTION

This device streams music and calls directly from your Bluetooth device to your vehicle's FM stereo system. The built-in microphone provides you with an amazing hands-free function, it also has dual USB ports that support charging. One button to activate BASS sound. This way, providing you with the real "hands-free" experience. Please read the User Manual before using.

PACKAGE CONTENTS

1x Bluetooth FM Transmitter
1x User Guide
1x 3.5mm Aux Cable

SPECIFICATIONS

Bluetooth Version	V5.0
Frequency Range	87.5-108.0MHZ
Product Input	10-30V
Bluetooth Distance	~ 7m
Charger Output	USB A - 5V/3A 9V/2A 12V/1.5A USB C - 5V/3A 9V/2.22A 12/1.66A
Music Format	MP3/WMA/WAV/FLAC/APE
Size of Screen	16 x 27mm(White LED)
Product Size	71 x 70 x 200mm
Product Weight	76g

FEATURES


- Wirelessly Transmits Phone Calls from Bluetooth device to the Vehicle's FM Stereo System
- Stream Music from Bluetooth Device to Vehicle's FM Stereo System
- Switch to Hands-free Mode Automatically from Music Playing when Receiving Calls
- Built-in Microphone
- 1x USB A with QC3.0 and 1x USB C with 20WPD
- Support Line In & Line Out
- One Button to Trigger Bass Booster
- Flexible Gooseneck for Multiple Angle Viewings
- 206 Channels Optional from 87.5-108MHz
- Big Rotary Knob for Easy Operation
- With Voice Prompt

PRECAUTIONS

Please read all safety instruction warnings carefully before using this product. Improper use of this product may result in damage to this or attached products. To ensure the products work well, please never use this in the following conditions :

- Moist or underwater conditions
- Conditions near heater or high-temperature service
- Conditions with direct and strong sunshine
- Never dismantle the product, otherwise it may nullify the warranty clause
- Do not use device while vehicle is in motion

OPERATION INSTRUCTIONS



1	Bass Button
2	Frequency Switch Power On/Off
3	Aux In / Aux Out
4	Built-in Microphone
5	Rotation / Call
6	USB C with 20WPD
7	USB A with QC3.0



Short Press

1. Answer the call
2. Hang up the call
3. When playing music, pause or play music.

Double Press

Re-dial the last number

Long Press


Reject the call

Short Press CH: (the LED display keeps flashing)

- Rotate the volume knob clockwise to increase the frequency
- Rotate anti-clockwise to decrease the frequency

OPERATION INSTRUCTIONS (continued)

Song Selection




Next

Prev

Rotate clockwise to play the next track

Rotate anti-clockwise to play the previous track

Volume Adjust



Vol +

Vol -

Rotate clockwise and hold for a while to increase volume

Rotate anti-clockwise and hold for awhile to decrease volume




Using FM Transmitter Function

1. Plug the FM transmitter into your vehicle's Accessory Socket.
2. Tune your radio to an unused FM frequency, then match the same frequency of this unit.
3. Follow the illustrations above to control your music easily.

Using Bluetooth Function

1. Using Bluetooth for the first time, you need to pair your mobile phone with this unit. Activate your device's Bluetooth function, then search for new device. When your device detects the unit (named "AR3146"), please pair and connect. The original password is "0000" if requested.
2. On the music playing mode, whenever there is an incoming call, this unit will automatically switch to call mode.

Bluetooth Calling

1. Press  to answer the incoming call.
2. Press  to hang up a call.
3. Press  twice to dial the last number.
4. When making a call, you can only dial the phone number by your mobile phone, but once the call connected, you can use the hands-free function.

OPERATION INSTRUCTIONS (continued)

Using USB Charger Function

Connect the USB charger port to your device, with a USB cable (not included) when this product is powered.

Bass Button

Press the Bass button to increase the bass.

How to Activate Voice Assistant (e.g. Siri/Google assistant)

Long press  to quickly access voice assistant (e.g. Siri/Google assistant).

Distributed by:
Electus Distribution Pty. Ltd.
320 Victoria Rd, Rydalmere
NSW 2116 Australia

www.electusdistribution.com.au

Made in China