

digitech

FM Transmitter

with Voice Commands, Bluetooth® Compatible,
USB Type C Power Delivery 20W



Model:
AR3148

Instruction Manual

WARNING & SAFETY INFORMATION

Please read all safety instruction warnings carefully before using this product. Improper use of this product may result in damage to this or attached products. To ensure the products work well, please never use this in the following conditions:

- Moist or underwater conditions.
- Conditions near heater or high-temperature service.
- Never dismantle the product without due permission, otherwise it may nullify the warranty clause.
- Check local legislation prior to using on public roads
- Ensure safe use of operating a vehicle, keep your eyes on the road and maintain safe driving practices at all times

BOX CONTENTS

1x Bluetooth® Compatible FM Transmitter 1x User Guide

FEATURES

- Wireless transmit phone call & audio playing to the car FM stereo system via Bluetooth®;
- Switch to Hands-free mode automatically from music playing status when receiving calls;
- Adjustable goose-neck design allows us to find a better viewing;
- Elegant design with big white LED display;
- Support to read Micro SD (Max 64 GB);
- Dual USB output PD20W+DC 5V/2.4A;
- Voice prompt and hands-free calling for safety driving;
- Adopt the Bluetooth® 5.3 Technology;
- Siri/Google assistant quick activation.

OPERATING INSTRUCTIONS




Setup the FM Transmitter Connection

- Plug the unit into your vehicle's cigarette lighter or power port.
- Tune your radio to an unused FM frequency, then match the same frequency of this unit.
- Insert Micro SD card or USB disk which containing MP3/WMA/WAV/FLAC files into the card/USB slot. It will play and transmit the file automatically.


Using Bluetooth® function

- Using Bluetooth® for the first time, you need to pair your mobile phone with this unit. Activate your mobile phone's Bluetooth® function, then search new device. When the mobile phone detects this unit (named as "**Digitech - AR3148**"), please pair or connect.
- On music playing mode, when there is an incoming call, this unit will automatically switch to telephone mode.






Bluetooth® calling

- Please press  to answer the incoming call or hang off a call.
- Please press  and hold for 3 seconds during call to reject the incoming call in Bluetooth® calling mode.
- Please press  twice to dial the last Number automatically.
- When making a call, you can only dial the phone number by your mobile phone, but once the call connected, you can use the hands-free function to enjoy it.

Activating Voice Assistant (e.g. Siri/Google assistant)

Press "" to quickly access voice assistant.

QUICK GUIDE

Play and Pause the music	Press "  " and hold for 3 seconds to reject incoming calls
Last number redial	Press "  " twice to dial the last number automatically.
Private calling	When answering a call ,press "  " and hold for 3 seconds to switch to private call mode.
Play and Pause the music	Press "  " Button: Play the music Press "  " Button again: Pause playing
Adjust the Volume	Press "^" and hold for 2 seconds to increase the Volume Press "v" and hold for 2 seconds to decrease Volume
Frequency modulation	Press "CH" and then press "^" to increase the frequency Press "CH" and then press "v" to decrease the frequency
Music selection	Press "^" Button: Play the previous song Press "v" Button: Play the next song

SPECIFICATIONS

Bluetooth® Version	5.3
Frequency range	87.6-107.9MHZ
Frequency stability	±10ppm
Product Input	12-24V
Dual USB output	PD20W+DC 5V/2.4A
Micro SD Card (Max Capacity)	64GB
Music Format	MP3/WMA/WAV/FLAC
Product Dimensions	59*90*127 mm
Product Weight	73.3g

WARRANTY INFORMATION

Our product is guaranteed to be free from manufacturing defects for a period of 12 Months.

If your product becomes defective during this period, Electus Distribution will repair, replace, or refund where a product is faulty; or not fit for intended purpose.

This warranty will not cover modified product; misuse or abuse of the product contrary to user instructions or packaging label; change of mind and normal wear and tear.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and failure does not amount to a major failure.

To claim warranty, please contact the place of purchase. You will need to show receipt or other proof of purchase. Additional information may be required to process your claim.

Any expenses relating to the return of your product to the store will normally have to be paid by you.

The benefits to the customer given by this warranty are in addition to other rights and remedies of the Australian Consumer Law in relation to the goods or services to which this warranty relates.

This warranty is provided by:

Electus Distribution

Address 46 Eastern Creek Drive, Eastern Creek NSW 2766

Ph. 1300 738 555