


**digitech**


# 13-30" LCD Monitor Wall Mount Bracket with Swivel & Tilt



Model:  
CW2902

# Instruction Manual

# Installation Instructions



## UNPACKING INSTRUCTIONS

! Carefully open the carton, remove contents and lay out on cardboard or other protective surface to avoid damage.

! Check package contents against the Supplied Parts List in the next page to assure that all components were received undamaged. Do not use damaged or defective parts.

! Carefully read all instructions before attempting installation.

## IMPORTANT SAFETY INFORMATION

Install and operate this device with care. Please read this instruction before beginning the installation, and carefully follow all instructions contained herein. Use proper safety equipment during installation.


Please call a qualified installation contractor for help if you:

! If you don't understand these directions or have any doubts about the safety of the installation.


! If you are uncertain about the nature of your wall, consult a qualified installation contractor.

Do not use this product for any purpose or in any configuration not explicitly specified in this instruction. We hereby disclaims any and all liability for injury or damage arising from incorrect assembly, incorrect mounting, or incorrect use of this product.


# Supplied Parts




(1) Wall Plate-a




(1) Mornitor Bracket-b




(1) Cap-c




(4) M4x12 Bolt-d




(4) M4x30 Bolt-e




(8) M4 Washer-f




(4) M4 Space-g



(2) Lag Bolt-h



(2) Concrete Anchor-i



(1) Safety Knob with washer-j



**WARNING**

## CAUTION!

**This TV mount must be securely attached to the vertical wall. If the mount is not properly installed it may fall, resulting in possible injury and/or damage.**

### Tools Required

■ 3.8mm Drill Bit

■ Phillips Screwdriver



■ 8mm Masonry Bit

■ Carpenter's Level



**Note:** The mounting components and hardware supplied in this package are not designed for installations to walls with steel studs or to cinder block walls. If the hardware you need for your installation is not included, please consult your local hardware store for proper mounting hardware for the application.

# Step 1 Mounting the Wall Plate to the Wall


## Brick Mount




## Wood Mount



## Step 2 Mounting the Monitor Bracket to the TV





For Flat Back TV



For Curved Back TV

## Step 3 Attaching TV to the Wall Plate & Adding the Knob



Distributed by:  
Electus Distribution Pty Ltd  
46 Eastern Creek Dr,  
Eastern Creek NSW 2766 Australia  
Ph 1300 738 555  
Int'l +61 2 8832 3200  
Fax 1300 738 500

[www.electusdistribution.com.au](http://www.electusdistribution.com.au)