



GH1138

Electric Air Pump

600L/min Airflow




INSTRUCTION MANUAL

SAFETY INFORMATION

- For adult use only.
- Do not drop the equipment into water or expose it to rain or moisture.
- Do not direct airflow toward the face or body.
- Do not block the vent.
- Do not insert objects into the air inlet or outlet.
- This product contains a battery. Do not allow it to come into contact with liquids, and keep it away from fire or environments exceeding 50°C.
- When the air pump shuts down due to low power protection, turn off the switch before recharging.
- Ensure the pump is given adequate time to cool between uses


PRODUCT OVERVIEW




- | | | |
|------------------------|------------------------|-----------------------|
| 1. Pump | 4. Charging port | 6. Nozzles |
| 2. Inflation Connector | 5. Deflation Connector | 7. USB Charging Cable |
| 3. Switch | | |

OPERATING INSTRUCTIONS

1. Install the special valve onto the inflatable port of the air pump, as shown in Figure (1).
2. Insert the air pump with the attached nozzle into the valve and tighten it clockwise, as shown in Figure (2).
3. Press and hold the power button for 2 seconds to turn the pump on. Press it again to turn it off, as shown in Figure (5).
4. Once inflation is complete, remove the air pump and turn the valve cover clockwise to close it, as shown in Figure (3).



5. Install the nozzle into either the inflation or deflation port, depending on your use.
6. If needed, choose and attach a suitable nozzle based on the valve type of the inflatable item (see Figure 4).
7. Press and hold the power button for 2 seconds to turn the pump on. Press it once again to turn it off (see Figure 5).



MAINTENANCE

- No specific maintenance is required. The air pump has no user-serviceable parts.
- The batteries are permanently sealed within the pump and cannot be removed or replaced. Recharge the batteries as the pump begins to weaken—do not wait until they are fully discharged.
- Do not dispose of the air pump or its batteries in fire. Refer to local regulations for proper disposal methods.
- Keep the pump away from heat sources and direct sunlight.

WARRANTY INFORMATION

Our product is guaranteed to be free from manufacturing defects for a period of 12 Months.

If your product becomes defective during this period, Electus Distribution will repair, replace, or refund where a product is faulty; or not fit for intended purpose.

This warranty will not cover modified product; misuse or abuse of the product contrary to user instructions or packaging label; change of mind and normal wear and tear.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and failure does not amount to a major failure.

To claim warranty, please contact the place of purchase. You will need to show receipt or other proof of purchase. Additional information may be required to process your claim.

Any expenses relating to the return of your product to the store will normally have to be paid by you.

The benefits to the customer given by this warranty are in addition to other rights and remedies of the Australian Consumer Law in relation to the goods or services to which this warranty relates.

This warranty is provided by:

Electus Distribution

Address 46 Eastern Creek Drive, Eastern Creek NSW 2766

Ph. 1300 738 555