



GH1295

Portable Rechargeable Camping Fan



User Manual

1. Product Specifications

Model No.: GH1295

Cell Type: Polymer Lithium-Ion Battery

Capacity: 10000mAh

Type-C Input: 5V/2A

USB Output: 5V/1A

Fan Power: 4W

LED Light Setting: 3 Settings

Timing setting: 4 Settings 1h/2h/3h/4h


Size: 214.5x115x240.4mm

Material: ABS + PP

Working time: 7-24 hours

Charging time: 5-6 hours

2. Diagram



3. Instructions

1. Fan speed: Rotate the dial clockwise to increase the fan speed.
2. LED Lamp: Each press of the button increase the brightness. After the third press, the lamp will turn off.
3. Timing setting: Each press of the button will increase the timer setting by 1 hour. After the fourth press, the timer will be cancelled.

4. Charging status:

1. Connect the USB Type-C cable to the Type-C input port.
2. The power indicator will flash blue when charging.
3. The power indicator will stay lit when fully charged.

5. Contents

- 1x Fan
- 1x USB Type-C charging cable
- 1x User Manual

6. Attention

1. This product is not a toy. Children should not use this product without the supervision of an adult.
2. Avoid using the fan in a humid environment to avoid damage.
3. Please charge the fan via a power source of DC 5V voltage and unplug the charging cable when charging is complete.
4. Avoid placing the fan near a fire/flammables.

5. Stop use of the fan when it gets too hot.

6. Product should be used in an environment where the temperature is between 0 to 40°C

7. Please do not dismantle, change or repair the product.

8. If the fan does not charge, try a different charging cable or a different power source.

Distributed by:
Electus Distribution Pty Ltd
46 Eastern Creek Dr,
Eastern Creek NSW 2766 Australia
Ph 1300 738 555

www.electusdistribution.com.au