



BATTLE GUNS

LASER TAG INSTRUCTION MANUAL




- LIFE INDICATORS: EACH LIFE INDICATOR REPRESENTS 3 HEALTH POINTS (FOR A TOTAL OF 9)
- LOW BATTERY: ALL LIFE INDICATORS WILL FLASH SLOWLY TO INDICATE THAT THE GUN HAS LOW BATTERY
- SHOOTING RANGE: 10-40m.


BATTERY INSTALLATION



Use a screwdriver to remove the battery cover



Insert 3 AAA batteries(not included). Make sure the batteries are inserted with the correct polarity.



Replace the battery cover.

WARNINGS REGARDING BATTERIES

- Do not mix alkaline standard (carbon zinc) and rechargeable (nickel hydride) batteries.
- Do not mix old and new batteries.
- Non-rechargeable batteries should not be charged.
- Rechargeable batteries should be charged under adult supervision only.
- Exhausted batteries should be removed.
- The supply terminals should not be short-circuited.
- Do not put batteries next to or in a heat source (fire, electronic heating device, etc.)
- Do not hit batteries against hard objects.
- Do not submerge batteries in water.
- Batteries should be inserted with the correct polarity.

OPERATION INSTRUCTION

- 1 Switch the gun on(It will play the start sound and team light will flash different color). The gun will default to Single shot.
- 2 Team selection of gun: Press the team selection button to toggle between teams. There are 4 colors to represent possible teams – blue, red, green or white. You cannot shoot your own team. A player cannot change teams during a game.
- 3 Gun modes and shots selection: Press button (FIRES) to toggle between 4 gun modes:


| Gun Modes | Single shot | Laser gun | Machine gun | Plasma gun |
|-----------------------------|-------------|-----------|-------------|------------|
| Shots | | | | |
| Health reduced by each shot | | | | |

When you run out of ammo, press the reload button under the grip to reload.

- 4 Aim and shoot at an opponent's gun to register a hit. Once hit, the health points counter will reduce accordingly and the gun will vibrate and emit a sound. Each life indicator will show a different level of health:
 Lost 1 health point = Slow blinking,
 Lost 2 health points = Fast blinking,
 Lost 3 health points = light will be dark.
 When all health points reaches 0, all indicators will be dark and then flash, you will be unable to fire anymore.

NOTE: Gun has 3 live indicators, this represents 9 health points.

Health points counter diagram



RESET GUN

- A player cannot change teams or reset a gun during a game.
- Press the team selection button to change your team before a game.
- To reset a gun, switch the gun off and on.

TROUBLE SHOOTING

| Problems | Possible reasons | Solutions |
|---------------------------|--|--|
| Products without function | The batteries are installed incorrectly or they are damaged. | Reinstall the battery or change the battery. |
| | The switch is off. | Make sure the switch is on. |
| Failure to hit aims | Shot your teammates. | Try to shoot your opponents. |
| | The bullets haven't been reloaded after shifting the gun type or they have been used up. | Press the " reload " button to reload the bullets. |
| | Failure to aim at opponents or it exceeds maximum distance. | Aim at the targets, shorten the shooting distance. |
| | Obstacles existing between two shooters. | Avoid obstacles. |

TROUBLE SHOOTING

| Problems | Possible reasons | Solutions |
|----------------------|--|---|
| Not Functioning | Low battery power, the life indicators flash at the same time. | Replace new batteries or charge(only for rechargeable batteries). |
| | Affected by the other infrared devices (like TV remote control). | Don't use the other infrared devices when playing with the toy. |
| Reduced firing range | Using the laser tag in strong sunlight. | Block sunlight or play in an area without strong sunlight. |

NOTE: If the product is not operating or functioning normally: Reset the product by powering it off completely. If it is still not operating correctly replace the batteries and double check the surrounds for interference.

Maintenance And Repair

- Please remove batteries if you do not use this product for a long time.
- Clean this product regularly with damp cloth.
- Avoid heat and exposure to the sun.
- DO NOT immerse the gun in water, or the electronic parts will be damaged.



WARNING: DO NOT modify the product without authorization, or it may lead to product failure or inability to control.



This product does not involve actual lasers; it uses safe infrared technology . The beam is not visible.

Distributed by:
 Electus Distribution Pty Ltd
 46 Eastern Creek Dr,
 Eastern Creek NSW 2766 Australia
 Ph 1300 738 555
 Int'l +61 2 8832 3200
 Fax 1300 738 500