


2. Function of transmitter buttons:

(1). Press the button of the remote control to start the stunt car. The function indicator on the remote control will light up as the button of the remote control is pressed (press any button of the remote control, the function indicator of the remote control will light up).

(2) When pressing the forward/backward button, the stunt car can go forward/backward.

(3) When pressing the left/right button, the stunt car can rotate left/right.





Caution

- The car body with 3.7 V Li-ion rechargeable battery, transmitter with 4*1.5V AA batteries (excluded).
 Batteries are to be inserted with the correct polarity;
- · Non-rechargeable batteries are not to be recharged;
- · Rechargeable batteries are only to be charged under adult supervision;
- · Different types of batteries or new and used batteries are not to be mixed;
- · The supply terminals are not to be short-circuited;
- When the speed slows down, it means that there is not enough electricity in the car body, please charge the car;
- When the controller has low power, the match frequency light will darken or off,please change the battery of the controller; • Please identify the charging jack and charging port when charging;
- · Please take batteries out from transmitter when it's not in use for a long time, and turn power switch to "OFF";
- Unpacking should be carried out under the guidance of adults;
- The packaging contains important information, it should be retained.

Warranty Information

Our product is guaranteed to be free from manufacturing defects for a period of 12 Months. If your product becomes defective during this period, Electus Distribution will repair, replace, or refund where a product is faulty; or not fit for intended purpose. This warranty will not cover modified product; misuse or abuse of the product contrary to user instructions or packaging label; change of mind and normal wear and tear. Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and failure does not amount to a major failure. To claim warranty, please contact the place of purchase. You will need to show receipt or other proof of purchase. Additional information may be required to process your claim. Any expenses relating to the return of your product to the store will normally have to be paid by you. The benefits to the customer given by this warranty are in addition to other rights and remedies of the Australian Consumer Law.

This warranty is provided by: Electus Distribution Address 46 Eastern Creek Drive, Eastern Creek NSW 2766 Ph. 1300 738 555