

## MINI HANDHELD

GT4278

# GAMING CONSOLE




USER MANUAL

## Safety & Warnings

1. When not in use, please turn off the game console to preserve the battery time.
2. Do not open the case of the gaming console to avoid damage of the unit.
3. Do not expose the product to water or liquids to prevent damage.
4. Do not expose the product to higher temperatures as it may damage the unit.

## Product Diagram



## Operation

1. Press the power on/off button to turn the game console on.
2. Press the mode button to change between A-Z games.
3. Press the directional buttons up and down to change between levels 1-99 of that selected game.
4. Press the start button to start the selected game.
5. Press the power on/off button again to turn the unit off when not in use.

Note: Press the sound button to mute the current sounds coming from the game console.

## Specifications

LCD: 1.22"

Run Time: Up to 180 Hours

Batteries: 2 x LR44 (Included)

Dimensions: 77(W) x 54(H) x 27(D)mm



**WARNING – KEEP BUTTON BATTERIES OUT OF REACH OF CHILDREN**

- If swallowed a lithium button battery may lead to serious or fatal injury in as little as 2 hours, due to chemical burns and potential perforation of the oesophagus
- All button batteries must be kept away from children regardless if they are new or used.
- If you suspect your child has swallowed or inserted a button battery immediately call the 24-hour Poisons Information Centre on 13 11 26 (Australia) or 0800 764 766 (New Zealand) for fast, expert advice.
- If your child is having difficulty breathing contact 000 (Australia) or 111 (New Zealand).
- Dispose of used button batteries immediately and safely out of the reach of children. A battery can still be dangerous even when it can no longer operate the device.
- As soon as you have finished using a button battery, put sticky tape around both sides of it. This will make it harder for children to swallow the button battery and avoid the risk of the battery catching fire.
- Immediately dispose of button batteries immediately out of reach of children, or recycle using a child resistant container and take used cells to your local battery collection centre.

Distributed by: Electus Distribution Pty Ltd  
46 Eastern Creek Dr, Eastern Creek NSW 2766 Australia  
1300 738 555 | [electusdistribution.com.au](http://electusdistribution.com.au)