

1:16

8+
AGES

1:16 WI-FI FPV R/C CAR


GT4291

2.4GHz


**Specifications:**

Speed: Up to 20km/h
 Frequency: 2.4GHz Digital
 Remote Control Range: Up to 50m
 Camera Resolution: 1080p (1920 × 1080) @ 25fps
 microSD Capacity: Up to 32GB


Play Time: Up to 15 Minutes
 Charging Time: Up to 2 Hours
 Batteries:
 Car: 1 x 7.4V Li-Ion, 500mAh (Included)
 Remote: 4 x AA (Not Included)
 Dimensions: 315(L) x 193(W) x 120(H)mm

Product Diagram**Trimming Settings**

When the car is moving to the left, adjust the trim to the right. Until the car returns to a straight line.







When the car is moving to the right, adjust the trim to the left. Until the car returns to a straight line.


**Battery Installation**

1. Open the battery cover. Follow Picture 1 to install 4 AA batteries into the remote control and then cover the battery cover.
2. Open the battery cover and plug the battery pack into the vehicle's power port as shown in Picture 2.
3. Load the battery pack into the battery box and then cover.


USB Charger

**Operation**


1. Forward: pull down the accelerator and drive the vehicle forward. Adjust the throttle force to control the speed of the vehicle.




2. Reverse: push the throttle forward and the remote control car backward. Adjust the throttle to control the speed of the remote control car.




3. Go forward and turn left: pull down the gas pedal while turning the left steering wheel.



4. Go forward and turn right: pull down the gas pedal while turning the left steering wheel.




5. Reverse and turn left: push the throttle forward while turning the steering wheel to the left.



6. Reverse and turn right: push the throttle forward while turning the steering wheel to the right.

USB Charging

Remove the battery from the car , Connect the USB charging cable to the computer USB interface , while Another section is connected to the battery port.




Tips:
USB light is on when charging.
USB lights out when full.
The charging time is 120-150 minutes.

Safety

- When the car is moving, please do not touch the four wheels of the remote control car with your hands to avoid the risk of twisting and cutting.
- When the power of the remote control or remote control car is insufficient, the remote control distance will be affected, and there will be a situation where the driving is too slow or the climbing is difficult.
- Don't let the remote control car fall or crash heavily, so as not to damage the remote control car or shorten the life of the remote control car.
- Don't play on roadsides, puddles, dirt or other dangerous places to avoid danger.

- 1.If not using this product for a long time, please remove the battery to avoid leakage or damage to the product.
- 2.Use a damp cloth to gently wipe the car.
- 3.Don't put the toys on the high temperature, moisture and direct sunlight.
- 4.Don't put toys in water, which may cause damage to electronic components.
- 5.Products sold Once , any security problems produced by the operation and use, control and other aspects, not be responsible by the factory.
- 6.In case of any problems such as use, operation and maintenance, technical support and after-sales service, Please contact the local distributor.

Camera Installation



Camera installation

Camera power link

Warning: The port just for camera, but not for charging, please do not charging here.

Phone Holder installation

APP Download and Install

Scan the Below QR code to download.



App Name: HENGQI PLAY

1. Connect the camera to the car, and the camera indicator light keeps on.
2. Go to your phone's Settings and find the WIFI list called "WiFi FPV Car" and connect.(see shown picture)
3. Open HENGQI PLAY APP, Click "START" enter into the APP interface, If connect correct, that you can see the FPV on the interface and Start to control it.



Battery Safety

- The use of batteries has certain risk, it may cause personal injury, or property damage.
- Use only factory supplied charger. Before cleaning the model, make sure the model is disconnected from the charger.
- Do not charge or use the swelling, leaking or damaged battery.
- Do not overcharge the battery. When the battery are fully charged, pull out the charge. After charge complete, do not recharge to avoid overheat.
- Do not charge near combustible or flammable (carpet, wood floor, solid wood furniture, etc.) or on surface of conductive objects. Should observe the battery at any time.
- Don't charge when the battery is still hot.
- The temperature of the battery is between 0 C and 40 C .
- Pull out the charger when not charged.
- Do not use plastic packaging has been damaged batteries.
- When the product is turned on, do not insert or remove the battery.
- Do not allow the battery to excessive physical shock.
- Do not use the expansion, leakage, breakage, or emits an odor of the battery.
- Children contact with battery is prohibited.
- Do not put battery into the fire, to avoid contact with liquid, the model can not be exposed to the rain, and should not be placed in the damp place.
- Please do not remove the battery or cut, drill. The battery or charger can not carry heavy things. Do not knock the battery.
- Do not use solvents, alcohol, or other flammable solvents to clean the charger.
- Prevent the short circuit. Avoid direct contact with electrolytic material of the battery, electrolytic material and electrolytic steam is harmful to the body.

Warranty Information

Our product is guaranteed to be free from manufacturing defects for a period of 12 Months. If your product becomes defective during this period, Electus Distribution will repair, replace, or refund where a product is faulty; or not fit for intended purpose. This warranty will not cover modified product; misuse or abuse of the product contrary to user instructions or packaging label; change of mind and normal wear and tear. Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and failure does not amount to a major failure. To claim warranty, please contact the place of purchase. You will need to show receipt or other proof of purchase. Additional information may be required to process your claim. Any expenses relating to the return of your product to the store will normally have to be paid by you. The benefits to the customer given by this warranty are in addition to other rights and remedies of the Australian Consumer Law in relation to the goods or services to which this warranty relates.

This warranty is provided by: Electus Distribution
Address 46 Eastern Creek Drive, Eastern Creek NSW 2766 Ph. 1300 738 555