14+

GT4346

1:14 SCALE BRUSHLESS RC HIGH SPEED 4WD TRUGGY



R-NZ

In order or operate this remote control car more easily, proficiently and safely, please read this instruction manual carefully before operation. The instruction manual contains important information, please properly keep it.

WARNINGS

- Not suitable for children under 3 years, small parts may present a choking hazard.
- Recommended for children aged 14 years and over.
- Adult supervision is required during operation.
- Remove all packaging materials before giving the toy to a child and dispose of the materials safely.
- Do not stick your fingers in the wheels of the truggy while moving.
- Do not modify or attempt to repair the truggy.
- Do not touch the motor after use while its hot.
- Do not use the truggy if any component is damaged or loose.
- Keep the truggy away from water, heat or excessive moisture.

Operation & Care:

- Only operate the truggy indoors or in a suitable open area away from obstacles.
- Switch off the truggy when not in use.
- Store the product in a cool, dry location away from direct sunlight.
- Clean the product using a soft, dry cloth.
- Do not use water, solvents or abrasive cleaners.
- Do not immerse any part of the product in water.

Battery Charging & Safety:


- The rechargeable battery must only be charged by an adult or under direct adult supervision.
- Only use the supplied USB charging cable.
- Connect the charging cable to a suitable 5V USB power source.
- Do not use a damaged charging cable, battery or USB power source.
- Charge the product indoors in a dry, well-ventilated location.
- Place the product on a hard, flat and non-flammable surface while charging.
- Do not leave the product unattended while charging.
- Do not charge the product overnight.
- Disconnect the charging cable when charging is complete.
- Do not operate the truggy while it is charging.
- Do not cover the truggy or charging cable during charging.
- Keep the product away from fire, direct sunlight and excessive heat.
- Do not attempt to remove or replace the internal battery unless the product is specifically designed for user replacement.
- Stop charging immediately if the battery becomes hot, leaks or shows any sign of damage.
- Insert batteries according to the polarity markings inside the battery compartment.
- Do not mix old and new batteries.
- Do not mix alkaline, standard carbon-zinc or rechargeable batteries.
- Do not mix batteries of different brands or capacities.
- Do not attempt to recharge non-rechargeable batteries.
- Rechargeable batteries must be removed from the remote control before charging.
- Rechargeable batteries must only be charged under adult supervision.
- Remove exhausted batteries immediately.
- Remove the batteries if the remote control will not be used for an extended period.
- Do not short-circuit the battery terminals.
- Do not dispose of batteries in fire.
- Keep new and used batteries away from young children.

PRODUCT PARAMETERS


Speed: Up to 50km/h
Frequency: 2.4GHz
Remote Control Range: Up to 100m
Play Time: Up to 20 Minutes
Charge Time: Up to 4 Hours

Batteries:
Truggy: 2S 7.4V Li-ion, 2000mA
Remote Control: 4 x AA (Not Included)
Dimensions: 320(L) x 240(W) x 135(H)mm

REMOTE CONTROL DIAGRAM



REMOTE CONTROL BATTERY INSTALLATION



Attention

1) The transmitter uses 4x1.5V "AA" non-rechargeable batteries.
2) Loading and unloading the battery should correctly operate according to the polarity and voltage marks on the battery box. The battery should not have any short circuit.
3) The non-rechargeable battery can not be charged.
4) The batteries of different types or new and old batteries can not be mixed in using

OPERATION


1.Throttle




2.Steering Wheel




3. Lighting switch





Short press to change the color of the Headlight and Underlight

BATTERY INSTALLATION OF THE VEHICLE



CHARGE THE BATTERY OF THE VEHICLE



After removing the battery, connect it to the USB charging port that comes with it, and then insert the other end of the charging cable into the charging interface (5V,2A)

When charging, the USB red night is always on and the green light is flashing. When fully charged, the USB red light and green light are always on.



1. Press the button on the battery to check the battery power.
2. When one red light on the battery flashing fast, it means that the battery is in a low state of power, please charge the battery immediately.

PAIRING




Turn on the transmitter.

2. Press and hold the Receiver as pic. switch

3. At this time, the lights of the transmitter and the car stay on, indicating that the frequency is successful matching.
⚠Note: Make sure the throttle lever is in the middle position. Do not touch the throttle lever when turning on the transmitter power.

ELECTRONIC SPEED CONTROLLER



PRECAUTIONS

1. When using the product, please keep away from the railway, highroad, and other dangerous environments.
2. In using the product, please keep away from the cellphone station, big-power emitting equipment and other environment with high electromagnetic interference.
3. In using the product, please keep away from the bike or car or the like.
4. Please do not use the product in raining, thunderstorm, sandstorm, frog, snow, strong wind, low temperature or other severe environment.
5. This product is not waterproof. Please do not operate the product near water.
6. Please always keep the remote control vehicle within the visual range of the operator.
7. Please do not operate the product near the site with children playing.
8. Please do not use the product chase after any transportation tool or affect the normal operation of the transportation tool.
9. The product can not be used after drinking, tiredness, taking medicine or having poor physical condition.
10. Please inspect the product before each operation, including but not limited to the firmness of the component, crack or wearing of the body and tire, battery power amount, effectiveness of the indicating light and so on. In case of any abnormality, please immediately stop using and replace the corresponding components
11. If car is acting irregular it is likely to have a accidental crash if used please give car a lookower before hand.
12. Please do not operate by force.
13. Please do not hinder any moving part
14. Please not refit the product, or use the product for any not originally designed application
15. Please operate as the instruction manual.
16. Please use the component of the original plant for maintenance and replacement.
17. It is not allowed to mix the batteries of different categories in using.
18. Please do not use the expanded, leaked or damaged battery.
19. In charging the battery, please do not approach any flammable product(such as blanket, wooden furniture and wooden plate and so on.)
20. Please use the charging line configured by the original plant. The charging line of other brand or the damaged charging line can not be used.
21. Please do not squeeze the battery or enable it to have short circuit, so as to avoid explosion.
22. The motor is hot, please do not touch it to avoid being burned.

WARRANTY INFORMATION

Our product is guaranteed to be free from manufacturing defects for a period of 12 Months.
If your product becomes defective during this period, Electus Distribution will repair, replace, or refund where a product is faulty; or not fit for intended purpose.
This warranty will not cover modified product; misuse or abuse of the product contrary to user instructions or packaging label; change of mind and normal wear and tear.
Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and failure does not amount to a major failure.
To claim warranty, please contact the place of purchase. You will need to show receipt or other proof of purchase. Additional information may be required to process your claim.
Any expenses relating to the return of your product to the store will normally have to be paid by you.
The benefits to the customer given by this warranty are in addition to other rights and remedies of the Australian Consumer Law in relation to the goods or services to which this warranty relates.

This warranty is provided by:
Electus Distribution
Address 46 Eastern Creek Drive, Eastern Creek NSW 2766
Ph. 1300 738 555