


SOLAR RECYCLER

Manual Assembly & Instruction








Think twice before discarding that 1985 CD-ROM, don't throw away that aluminum can, and pick up that plastic bottle left under the couch. We can use them with our state-of-the-art, eco-friendly educational toy kit that will stretch your child's imagination while allowing them to take part in the joy of recycling. The Super Solar Recycler Kit is powered completely by natural light so you never have to worry about batteries!


In addition to your newly discovered treasures, all you need to get started is included in this kit (solar panel, motor and instruction). Your children can recycle a can of their favorite soft drink to create Street Roller and Walking Robot, create Bottle Yacht, Drummer Robot and Flying Bird using a plastic water bottle, and even turn your old scratched CD's into the super cool CD Racer.


Let's have our children play in an eco-friendly way, and learn to harness a new green solar energy source as well as implement the use of recycled materials. We invite you to participate in the creation of a sustainable future.





























9 Completed








How To Work The Gear Box


Notice: Find and make sure correct direction of "◁ " on gearbox first, it would help you to install the parts correctly.
































Disassemble


CD & Plastic Parts


"Disassemble" This portion is a little unclear to me because I have yet to put it to practice but can we change the text to, "Remove the plastic bushings from the CDs as illustrated below. Release A4 from the front wheel and remove A15 or














































Adjust Robot's arm to have strong/or weak of drumbeat





Make your own unique tempo


Install B19 with different quantity and position as below figure.





Disassemble







































































It's time to have some FUN!







- 1. Take outside under direct sunlight. Best results are obtained when operated on a sunny day.
- 2. For indoor fun, use a 50 watt halogen light. The product will not run on a cloudy day, shaded locations, indirect sunlight, or under a Fluorescent light.







