

# **LR8882 Operation Manual**

## **Oneway remote control**



### Function

1.

Pressing button 1 will control relay 1.

Pressing button 2 will control relay 2.

Pressing button 3 will control relay 3.

Pressing button 4 will control relay 4.

2.

Press the button, and the LED will light up.

#### 3.

The silicone has a glowing function at night.

### Specification

Model name	LR8882
Remote Battary	1*27A 12V
Operationg Temperature	-5°C∼35°C
Dimension	44mm*52.7mm*20mm
Frequency	433.92MHz ± 75KHz
Modulation	ASK
Stand-by current	0.02uA~0.11uA
Emission current	7mA~9mA