

POWERTECH PLUS

In-Car Charger for Dash Camera and GPS Navigation MP-3683 User Manual

Introduction:

For safe and correct use, please read this manual carefully. It contains important operating instructions. Please keep this manual for later reference. This unit is specially designed for charging/powering dash cameras, GPS navigators, and other USB devices.

Specifications:

Input Voltage: 12 ~ 24V

Output:


USB-A Socket: 2.4A

Power Cord: 1.2A

Connector: Mini-USB

Weight: 85g

Cable Length: 3m



Charging USB Devices:

1. Before using, check your USB device's input voltage and this USB Car Charger's output voltage to ensure they match. Make sure the total loading does not exceed the rated output current of this Car Charger.
2. Connect the Car Charger and your USB device(s) with suitable USB cable(s). (To ensure complete safety and best performance, we strongly recommend using the original charging cable that came with your device)
3. Insert the Car Charger to car cigarette socket and the LED indicator will light on instantly.
4. The USB Car Charger will start charging your device automatically.
5. Your digital device should indicate it is now in charging mode.
6. Please unplug this Car Charger from car cigarette lighter socket when not in use.

Safety Instructions:

1. Do not short circuit.
2. Ensure correct voltage is used as continuous excessive voltage could damage your equipment.
3. Do not try to use this power supply with appliances requiring more than 2.4A (USB-A) / 1.2A (Mini-USB cable).
4. Do not attempt to open this unit.
5. Remove from car cigarette lighter socket when not in use.
6. Always turn off the digital device before you connect / disconnect the USB Car Charger.
7. Please start the car engine first before plugging in the USB Car Charger.

Disposal Instructions:

This product should not be disposed with other household wastes. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased.

iPad, iPhone & iPod are the trademark and properties of Apple Inc.

Distributed by:
TechBrands by Electus Distribution Pty. Ltd.
320 Victoria Rd, Rydalmere
NSW 2116 Australia

Ph: 1300 738 555
Int'l: +61 2 8832 3200
Fax: 1300 738 500

www.techbrands.com

Made in China