

**POWERTECH**

PP4015

# Multi Connection Universal Travel Adapter



## Instruction Manual


Please read and save all instructions to ensure safe and effective use of this product.



## CAUTION

- Always disconnect Adapter from the outlet when not in use.
- Please read instructions carefully before use.
- Indoor use only.
- Waste electrical products should not be disposed of with household waste. Please recycle where facilities exist. Check with your Local Authority for recycling advice.

## PRODUCT OVERVIEW



## OPERATIONAL INSTRUCTIONS

### Plug Selection

- Pick the plug that matches the country you're currently in and plug it into the back of unit.

### Plug Attachment

- Align plug with slot on main unit, they should click in easily.
- Push until a "click" confirms secure attachment and the plug shouldn't move after and be locked.

### Plug Detachment

- Press and hold release button on the side of main unit and pull back on plug away from unit.
- Pull plug from slot and it will release

## SPECIFICATIONS

Rating for US: 125Vac 60Hz, 10A Max, 1250W Max

Rating for DE/UK/CN: 250Vac 50Hz, 10A Max, 2500W Max

Operating Temperature: 0°C - 35°C

Adapter does not convert voltage

## WARRANTY INFORMATION

Our product is guaranteed to be free from manufacturing defects for a period of 12 Months.

If your product becomes defective during this period, Electus Distribution will repair, replace, or refund where a product is faulty; or not fit for intended purpose.

This warranty will not cover modified product; misuse or abuse of the product contrary to user instructions or packaging label; change of mind and normal wear and tear.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and failure does not amount to a major failure.

To claim warranty, please contact the place of purchase. You will need to show receipt or other proof of purchase. Additional information may be required to process your claim.

Any expenses relating to the return of your product to the store will normally have to be paid by you.

The benefits to the customer given by this warranty are in addition to other rights and remedies of the Australian Consumer Law in relation to the goods or services to which this warranty relates.



This warranty is provided by:

Electus Distribution

Address 46 Eastern Creek Drive, Eastern Creek NSW 2766

Ph. 1300 738 555