digitech

Screenless Smart Bracelet



Model:
QC3115

R-NZ

Please read and save all instructions to ensure safe and effective use of this product.

Instruction Manual

QUICK GUIDE TO USE

Your Smart Health Partner
This smart fitness tracker features a lightweight and comfortable design for all-day wear. It helps you monitor daily activity and health data, supporting a better understanding of your physical condition and daily habits.

How to Wear
- Wear the bracelet on your wrist, approximately one finger-width above the wrist bone.
- Ensure the sensor is in close contact with your skin.
- Do not wear the bracelet too tightly or too loosely, as this may affect measurement accuracy.

Charging and Activation
1. Charge the bracelet before first use.
2. Connect the magnetic charging cable to the charging contacts on the back of the bracelet.
3. Connect the USB plug to a suitable USB power source.
4. The indicator light illuminates red while charging.
5. The indicator light turns green when the bracelet is fully charged.

Water Resistance Rating
This smart fitness tracker has an IP68 water-resistance rating.
Do not charge the bracelet when it is wet. Wipe it dry before connecting the charging cable.

Radio Frequency Information
Operating Frequency Band: 2,402–2,480 MHz
Maximum Radio-Frequency Power: 2.56 dBm

APP DOWNLOAD AND CONNECTION

Android iOS

Download the App
1. Scan the QR code to download the Da Halo app.
2. Alternatively, search for Da Halo in the Apple App Store or Google Play Store.
3. Download and install the app on your phone.

Connect the Bracelet
1. Open the Da Halo app and complete your personal information.
2. Go to the Device page.
3. Tap Bind Device.
4. Select QC3115 from the scanned device list.
5. Once paired, the bracelet will automatically connect to the app.


Keep Bluetooth enabled on your phone while using the bracelet. For reliable synchronisation, allow the Da Halo app to run in the background.

HEALTH MONITORING FUNCTIONS

- Heart Rate Monitoring
- Sleep Tracking
- Stress Level Assessment
- Activity Tracking

IMPORTANT NOTES

- Fully charge the bracelet before first use.
- Avoid charging in humid environments.
- Ensure the charging contacts are clean and dry before connecting the charging cable.



POWER ON / OFF

Power On - Charge the bracelet using the supplied charging cable to activate it for first use.

Power Off - In the Da Halo app, go to:
Settings > Other Settings > Power Off

INDICATOR LIGHTS

- **Power On:** The light illuminates three times and the bracelet vibrates.
- **Power Off:** The red light illuminates three times and the bracelet vibrates.
- **Battery Low:** The red light flashes once every 5 minutes.
- **Not Connected to the App:** The red and green lights flash alternately every 5 minutes.
- **Connected to the App:** The green light flashes three times.
- **Charging:** The red light remains on.
- **Fully Charged:** The green light remains on.

SAFETY AND MAINTENANCE

- Avoid strong impacts and extreme temperatures.
- Keep the device clean and dry.
- Do not use or store the device near chemicals or corrosive substances.
- Stop using the device if skin irritation occurs.
- Remove the bracelet before showering to avoid water entering the charging contacts.
- Do not use the device on broken, irritated or damaged skin.
- Keep the device away from children when not in use.

DATA DISCLAIMER

The data provided by this device is for general information only. It is not intended for medical diagnosis or treatment.
For any health concerns, please consult a qualified healthcare professional.

RoHS R-NZ

WARRANTY INFORMATION

Our product is guaranteed to be free from manufacturing defects for a period of 12 Months. If your product becomes defective during this period, Electus Distribution will repair, replace, or refund where a product is faulty; or not fit for intended purpose.
This warranty will not cover modified product; misuse or abuse of the product contrary to user instructions or packaging label; change of mind and normal wear and tear.
Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and failure does not amount to a major failure.
To claim warranty, please contact the place of purchase. You will need to show receipt or other proof of purchase. Additional information may be required to process your claim.
Any expenses relating to the return of your product to the store will normally have to be paid by you. The benefits to the customer given by this warranty are in addition to other rights and remedies of the Australian Consumer Law in relation to the goods or services to which this warranty relates.

This warranty is provided by:
Electus Distribution
Address 46 Eastern Creek Drive,
Eastern Creek NSW 2766
Ph. 1300 738 555