QM3880

NEXTECH



TFT LCD Monitor

Instruction Manual

SAFETY FIRST

For your safety, please operate this unit in accordance with your local road and traffic regulations.

- · Do NOT watch video while driving
- · Do NOT install this product illegally
- · Use responsibly

PRODUCT OVERVIEW




- 1. Power
- 2. Mode
- 3. Decrease
- 4. Menu
- 5. Increase


FUNCTION & SPECIFICATIONS

7" Digital LCD Panel, 16:9 Resolution: 800x480 RGB Remote Control Included Video Standard: PAL & NTSC

Video Sources: 2 Power Supply: DC 12V

CONNECTION





BRACKET INSTALLATION

1. Use screws to lock bracket to the desired installation location.



2. Slide the metal head on the bracket into the gauge on the back of the monitor.





3. Once the monitor is placed at the right height, tighten the knob by turning it clockwise.



4. Untighten the knob on the ball head to change angle of the monitor.



Distributed by: Electus Distribution Pty Ltd 46 Eastern Creek Dr, Eastern Creek NSW 2766 Australia Ph 1300 738 555 Int'l +61 2 8832 3200 Fax 1300 738 500

www.electusdistribution.com.au

Made in China