



SL3130

Touch Control Folding Desk Lamp With USB Out



Instruction Manual


WARNINGS & SAFETY INFORMATION

Please read through these operating instructions carefully and thoroughly. These instructions form part of the product and contain important start-up and handling information. Always observe all the safety instructions. Please keep these instructions in a safe place, and pass them on, if necessary, to third parties.

Warning

- The light source in this product should be replaced by the manufacturer or its service agent, or a similarly qualified person.
- Keep this product out of reach of children
- Do not use this product in hot, humid places.

INSTRUCTIONS FOR USE



- The main power switch located on side of the body is used to control the power entirely. When this switch is in the off position there will be no light or powerbank functionality. The switch must be on to enable the lighting and powerbank to operate
- Short press the touch switch to power the light on, short press again to cycle between the different lighting colour temperature settings (cool/warm/natural white). Touch and hold while the light is on to adjust the brightness, repeat this step to dim the light brightness accordingly.
- This product has a built-in lithium battery bank which can be used to charge up portable USB devices like mobile phones, tablets and accessories. The RED light indicates the powerbank is being charged while plugged in to a suitable USB Type-C charging cable and a power source. Once the powerbank is fully charged the light will turn GREEN.
- Application scenario: bedroom, dormitory, camping, travels, campus, office, bedroom etc.

SPECIFICATIONS

| | | | |
|--------------|---------------|---------------|-----------------|
| Input: | USB-C (5V/1A) | Battery: | 10,000mAh |
| Lumen: | 120 | Product size: | 186 x 72 x 42mm |
| Charge Time: | Up to 12hrs | Weight: | 370g |
| Run Time: | Up to 17hrs | | |

WARRANTY INFORMATION

Our product is guaranteed to be free from manufacturing defects for a period of 12 Months.

If your product becomes defective during this period, Electus Distribution will repair, replace, or refund where a product is faulty; or not fit for intended purpose. This warranty will not cover modified product; misuse or abuse of the product contrary to user instructions or packaging label; change of mind and normal wear and tear.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and failure does not amount to a major failure.

To claim warranty, please contact the place of purchase. You will need to show receipt or other proof of purchase. Additional information may be required to process your claim.

Any expenses relating to the return of your product to the store will normally have to be paid by you.

The benefits to the customer given by this warranty are in addition to other rights and remedies of the Australian Consumer Law in relation to the goods or services to which this warranty relates.

This warranty is provided by:

Electus Distribution

Address 46 Eastern Creek Drive, Eastern Creek NSW 2766

Ph. 1300 738 555