



SL3560

Touch Lamp

with Hook



Instruction Manual

WARNINGS & SAFETY INFORMATION

Please read through these operating instructions carefully and thoroughly. These instructions form part of the product and contain important start-up and handling information. Always observe all the safety instructions. Please keep these instructions in a safe place, and pass them on, if necessary, to third parties.

Warning

- Do not install in a humid environment, under direct sunlight or near gas outlets.
- When the battery runs flat, ensure you charge the product back up to maximise the lifetime of the unit.
- Please do not attempt to open the product as this will void warranty.
- Charge unit only using a suitable 5V USB outlet.
- This product has an inbuilt battery, it is strongly advised not to disassemble, puncture or place into fire. If there are signs of swelling, do not continue to use the product.
- Once the LED Light source reaches its end of life it can not be replaced.
- Please keep this product out of reach of children and do not use this product in high temperature environments.


USAGE INSTRUCTIONS

Main ON/OFF Switch

Slide to ON position when you want to operate unit, slide to OFF position when not in use.

Touch Control

- Short press the touch switch in centre of light to turn on.
- Short press again to cycle between 3 colour temperatures (Cool,Warm, Natural)
- Short press a fourth time to switch unit off.
- Long press the switch when light is on to adjust the brightness to the desired level.
- While charging a RED light will be on, when the unit is fully charged it will turn GREEN.



SPECIFICATIONS

Input: USB-C (5V/1A)
Lumen: 60
Charge Time: 7hrs

Run Time: Up to 16hrs
Battery: 5,400mAh
Product size: 100 x 100 x 88 mm

WARRANTY INFORMATION

Our product is guaranteed to be free from manufacturing defects for a period of 12 Months.

If your product becomes defective during this period, Electus Distribution will repair, replace, or refund where a product is faulty; or not fit for intended purpose.

This warranty will not cover modified product; misuse or abuse of the product contrary to user instructions or packaging label; change of mind and normal wear and tear.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and failure does not amount to a major failure.

To claim warranty, please contact the place of purchase. You will need to show receipt or other proof of purchase. Additional information may be required to process your claim.

Any expenses relating to the return of your product to the store will normally have to be paid by you.

The benefits to the customer given by this warranty are in addition to other rights and remedies of the Australian Consumer Law in relation to the goods or services to which this warranty relates.

This warranty is provided by: Electus Distribution
Address 46 Eastern Creek Drive, Eastern Creek NSW 2766
Ph. 1300 738 555