




SL3702

Flexible Silicone Light Bar



Instruction Manual



Safety Notice

- Do not use this product for professional work such as tunnel construction.
- Do not look directly at the LED light, or shine it at people or animals.
- This product contains a built-in magnet. Never place it near devices sensitive to magnetism, such as precision instruments, magnetic cards, watches, or compasses.




Ideal for all scenarios including night work and outdoor activities.

Before Use



WARNING May cause serious injury or death.

- Do not throw into fire or immerse in water.
- Do not expose to rain or water.
- Do not charge in high-temperature environments.
Example: Direct sunlight or inside a vehicle
- Do not use the product if it has been dropped from a height or subjected to strong impact.



CAUTION May cause injury or equipment damage.


- Do not leave or store the product while it is turned on.

Intended Use


- Can be used for lighting during work at night or in dark places.
It can operate continuously for approximately 2.5 hours on a single charge (at HIGH brightness).
- ※ Approximate working time per full charge (at ambient temperature of 20°C)
- ※ These figures are estimates only. Actual performance may vary depending on usage conditions.

Parts Names

Main Unit



Accessories



Preparation Before Use


Charging Method

CAUTION

- Before charging, make sure the main unit has fully cooled down.
- Do not charge in dusty environments.

- Charging time may vary depending on ambient temperature and battery condition.
- Except when charging, always keep the cap of the charging port securely closed.
- The main unit may become warm during charging; this is not a malfunction.

1. Remove the cap from the charging port on the main unit, then insert the charging plug of the USB cable.
2. Insert the USB plug of the cable into the USB port of a commercially available AC adapter. When charging starts, the battery indicator will light up or flash according to the remaining charge level. If the indicator does not light up or flash, please check all connections.
3. When charging is complete, all 4 battery indicators will light up. Disconnect all connections.



To prevent malfunction, this product is designed not to turn on even if the switch is pressed while charging. Please use it only after the charging plug is disconnected.


Usage Instructions

How to Turn On & Adjust Brightness

- From the off state, press the switch to cycle through two brightness levels.



- This product uses an LED lamp, which is not replaceable.
- Due to variations in LED components, light color and brightness may differ even among units of the same model.



Using the Magnet Mount


- The product features two built-in magnets, allowing it to be attached to any desired metal surface.

**CAUTION**

This product uses strong magnets. Use caution when removing it to avoid scratching surfaces. Never place it near magnet-sensitive items such as precision instruments, magnetic cards, watches, or compasses.

Using the Hanging Hook

- Lift the hanging hook to suspend the product from poles, cords, or other hooks.



Switch



Hanging Hook



Specifications

Model	3.7V Rechargeable Flexible LED Light	
Bulb Type (Non-replaceable)	4907052 626737	
Continuous Lighting Time (Fully Charged)	COB White LED (non-replaceable)	
Total Luminous Flux	(HIGH): Approx. 2.5 hours	
	(LOW): Approx. 5 hours*1	
Operating Temperature	- (HIGH): Max. 1,600 lm	
	- (LOW): Max. 800 lm	
	*Brightness decreases as the battery drains.	
Charging Time (Approx.)	5-40°C	
Charging Plug Input Voltage	Up to 4.5 hours (empty to full) *when using a 2A AC adapter*2	
Charging Plug Input Current	2.0A *when using a 2A AC adapter	
Unit Dimensions	Approx. H 53 × W 945 × D 27 (mm)	
Weight	Approx. 340 g	
Charging Temperature Range	10-35°C	
Built-in Battery:	Battery Type	Lithium-ion (non-replaceable)
	Voltage	DC 3.7V
	Capacity	5,200 mAh
Cable Length	Approx. 0.9m (included USB cable)	
Country of Origin	China	
Expected Lifespan	5 years	

To the Customer
Please use an AC adapter with specifications equivalent to the charging plug mentioned above. Always use an adapter with an output current of 2.0A or higher. While it can handle up to 5V 3A, this product does not support fast charging (using a fast-charging adapter may cause malfunction).

- ※1 Lighting time is an estimate and may vary depending on the charge status and ambient temperature.
- ※2 Charging time may vary depending on the AC adapter, USB cable, temperature, and remaining battery level.
- ※After purchase, always perform a lighting test before use.

Care and Storage

- If heavily soiled, remove dirt with a brush and wipe with a cloth.
- Store in a cool, dry, well-ventilated place out of reach of children, or in a locked cabinet.
- Do not leave in high-temperature environments (e.g., direct sunlight or inside a car).
- Do not disassemble, modify, or repair the product yourself.
- If unused for an extended period (6 months or more), store the product with a fully charged battery.

Used battery packs or products with non-removable batteries cannot be disposed of as household waste.	
---	--

If you suspect a malfunction

■ Symptom	■ Cause	■ Solution
Does not turn on, or turns off immediately after being turned on.	Battery level is low.	Please charge the device.
The light is dim.	The light unit is dirty.	Please clean the light unit.
	Battery level is low.	Please charge the device.
Does not charge fully.	Poor connection of the power plug or USB terminal.	Please insert the plug firmly.

※ If the problem is not resolved by the above, do not attempt to repair it yourself. Please contact the store where you purchased the product.

WARRANTY INFORMATION

Our product is guaranteed to be free from manufacturing defects for a period of 12 Months.

If your product becomes defective during this period, Electus Distribution will repair, replace, or refund where a product is faulty; or not fit for intended purpose.

This warranty will not cover modified product; misuse or abuse of the product contrary to user instructions or packaging label; change of mind and normal wear and tear.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and failure does not amount to a major failure.

To claim warranty, please contact the place of purchase. You will need to show receipt or other proof of purchase. Additional information may be required to process your claim.

Any expenses relating to the return of your product to the store will normally have to be paid by you.

The benefits to the customer given by this warranty are in addition to other rights and remedies of the Australian Consumer Law in relation to the goods or services to which this warranty relates.

This warranty is provided by:

Electus Distribution

Address 46 Eastern Creek Drive, Eastern Creek NSW 2766

Ph. 1300 738 555