



SL3743

3-Blade Foldable Rechargeable Camp Fan



INSTRUCTION MANUAL

INTRODUCTION

Please read these operating instructions carefully before using this product. This manual contains important information regarding the safe operation, charging, and maintenance of the torch.

SAFETY WARNINGS

- This product is powered by one (1) 1500mAh rechargeable Li-ion battery. The battery is recyclable — please dispose of it responsibly through an approved recycling facility.
- The light source contained in this luminaire may only be replaced by the manufacturer, authorised service agent, or similarly qualified person.
- Fully charge the torch before first use.
- Do not use a modified or damaged charger or charging cable.
- Do not operate the torch while charging.
- Do not leave the torch charging for longer than 24 hours.
- Do not disassemble the torch or attempt to replace the battery yourself.
- If the torch is not used for extended periods, recharge it at least once every six months to maintain battery performance.
- This product contains a rechargeable Lithium-ion battery. Improper use may cause the battery to rupture, ignite, or result in serious injury.

Battery Safety Instructions

- DO NOT place the battery or device in fire or expose it to high temperatures.
- DO NOT tamper with battery wiring or connections.
- DO NOT puncture, crush, or damage the battery.
- DO NOT use batteries that appear swollen, leaking, or damaged.
- DO NOT immerse the battery or device in water.

OPERATING INSTRUCTIONS

Charging the Torch

- Before first use, fully charge the torch using the included USB-C charging cable.
- Connect the USB-C cable to a suitable 5VDC 1A USB power source.

Charging Indicator

- Red light: Charging
- Green light: Fully charged

SPECIFICATIONS

Product Size:	70 x 70 x 268 mm
Material:	ABS+PC
Bulb:	3W LED+SMD
Mode:	LED 100%-50%-SMD 25%-50%-100%-OFF
Lumens:	500 lm(SMD)+100 lm(LED)
Run time:	2H
Charging time:	4H
Battery:	3.7V 1500mAh Li-ion battery

WARRANTY INFORMATION

Our product is guaranteed to be free from manufacturing defects for a period of 12 Months.

If your product becomes defective during this period, Electus Distribution will repair, replace, or refund where a product is faulty; or not fit for intended purpose.

This warranty will not cover modified product; misuse or abuse of the product contrary to user instructions or packaging label; change of mind and normal wear and tear.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and failure does not amount to a major failure.

To claim warranty, please contact the place of purchase. You will need to show receipt or other proof of purchase. Additional information may be required to process your claim.

Any expenses relating to the return of your product to the store will normally have to be paid by you.

The benefits to the customer given by this warranty are in addition to other rights and remedies of the Australian Consumer Law in relation to the goods or services to which this warranty relates.

This warranty is provided by:

Electus Distribution

Address 46 Eastern Creek Drive, Eastern Creek NSW 2766

Ph. 1300 738 555