



SL3746

Portable Camping Lantern



INSTRUCTION MANUAL

BOX CONTENTS

1 x Camping Light
1 x TYPE C-USB A Charging Cable
1 x User Manual

SAFETY & WARNING

- The light produces very bright beam; avoid shining directly into eyes.
- Keep away from flammable surfaces/materials.
- Unplug when not charging, before servicing or cleaning.
- This is not a toy; keep out of reach of children.
- Never dispose lithium battery in fire (risk of leakage/explosion).
- Dispose according to local regulations.
- Unauthorized modifications void user's authority to operate the equipment.

OPERATING INSTRUCTIONS

Charging the Torch

- Before first use, fully charge the torch using the included USB-C charging cable.
- Connect the USB-C cable to a suitable 5VDC 1A USB power source.

Charging Indicator

- Red light: Charging
- Green light: Fully charged

To operate the unit

- Press the button once for 100% brightness
- Press the button twice for 50% brightness
- Press the button three times for 25% brightness
- Press the button four times for weak brightness mode
- Press the button five times to turn the unit off

SPECIFICATIONS

Product size: 127x105x202mm

Main material: ABS+PC

Bulb: 4x5W COB (High Intensity LED)

Mode: 100%-50%-25%-weak-OFF

Lumens: 1500lm

Product weight: 520g

Lighting distance: 10m

Waterproof grade: IP44

Run time: 2-6H

WARRANTY INFORMATION

Our product is guaranteed to be free from manufacturing defects for a period of 12 Months.

If your product becomes defective during this period, Electus Distribution will repair, replace, or refund where a product is faulty; or not fit for intended purpose.

This warranty will not cover modified product; misuse or abuse of the product contrary to user instructions or packaging label; change of mind and normal wear and tear.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and failure does not amount to a major failure.

To claim warranty, please contact the place of purchase. You will need to show receipt or other proof of purchase. Additional information may be required to process your claim.

Any expenses relating to the return of your product to the store will normally have to be paid by you.

The benefits to the customer given by this warranty are in addition to other rights and remedies of the Australian Consumer Law in relation to the goods or services to which this warranty relates.

This warranty is provided by:

Electus Distribution

Address 46 Eastern Creek Drive, Eastern Creek NSW 2766

Ph. 1300 738 555