

How to connect the 7pin TS1515 (ZD-552 heater):

1. There are 5 wires in the heater. The two short white wires(3,4) are heating core. The two long white wires(1,2) are thermocouple. The blue one is the ground. Pls see the right picture below.
2. Connect each of the two short white wires(3,4) with each of the two red wires in the left picture.
3. Connect the relatively short thermocouple wire(1) with the black wire in the left picture.
4. Connect the relatively long thermocouple wire(2) with the blue wire in the left picture.
5. Connect the blue ground wire with the yellow-green wire in the left picture.

