
digitech

# Portable Bluetooth® Soundbar



Model: XC5203




Please read and save all instructions to ensure safe and effective use of this product.

**Instruction Manual** 

# **BOX CONTENTS**

- · Speaker
- · Aux Cable
- · USB Cable
- User Manual

# **PRODUCT OVERVIEW**



- 1. 3.5mm AUX Input
- 2. DC 5V Power
- 3. SD Card Slot

- 4. ON/OFF Switch
- 5. USB Play

## **USAGE INSTRUCTIONS**

#### BT Mode

- BT Version:BT 5.3, support HSP, A2DP, AVRCP profiles, with voice prompts. BT pairing name:XC5203.
- 2. Rotate the volume knob to turn on the speaker, then the blue color indicator light is on with voice prompts.
- 3. The blue color light will flash by 100ms, and the speaker is on pairing status, use the device to serach"XC5203", then it will connect and pair automatically. If there is password needed, it is "0000". After connected successfully, there will be voice prompts. The blue color light will flash by 1000ms when the speaker is in using. Once the device is connected successfully, it will be automatically paired when re-use next time.

#### **AUX Mode**

- 1. Connect the device with the 3.5mm aux cable and the speaker will enter into the AUX mode with voice prompts.
- 2. The blue color indicator light is on in Aux mode.

#### **Charging Mode**

- Charge the speaker with the charging cable. (Wall charger is also available as long as it is 5V adapter).
- 2. The red color indicator light is on when it is on charging mode, and the light is off when fully charged.

#### Low battery protection

When the battery is lower than 3.3v and lasts for 15s, the speaker will issue the warning, and when the battery is lower than 3.1v and lasts for 15s, the speaker will issue the warning and turn off itself.

## M key

- · Long press to switch the brightness of the light.
- · Short click to switch function
- · Press twice to access the TWS function

### Disable TWS setting

- Switch the mode of one of the speaker to TF or FM by pressing M, then the TWS will get disconnected.
- 2. If you wish to establish TWS Connection again switch the mode back to BT mode and it will then connect automatically.

# **SPECIFICATIONS**

| Function              | BT/SD Card/USB/AUX-In/FM/RGB/TWS |
|-----------------------|----------------------------------|
| BT version            | 5.3                              |
| Rated Power           | 5W x 2                           |
| Playing time          | Up to hours                      |
| Transmission Distance | 10M                              |
| Horn size             | 52mm x 2                         |
| Impedance             | 4 ohm                            |
| Battery capacity      | 1200mAh                          |
| Charging time         | Up to 3 hours                    |
| Charging voltage      | 0.5A DC5V/USB POWER              |
| Frequency response    | 160hz-18khz                      |
| Material              | ABS+Iron net                     |
| Product size          | 372(L) x 70(W) x 55(H)mm         |
| Weight                | 556g                             |

#### WARRANTY INFORMATION

Our product is guaranteed to be free from manufacturing defects for a period of 12 Months.

If your product becomes defective during this period, Electus Distribution will repair, replace, or refund where a product is faulty; or not fit for intended purpose.

This warranty will not cover modified product; misuse or abuse of the product contrary to user instructions or packaging label; change of mind and normal wear and tear.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and failure does not amount to a major failure.

To claim warranty, please contact the place of purchase. You will need to show receipt or other proof of purchase. Additional information may be required to process your claim.

Any expenses relating to the return of your product to the store will normally have to be paid by you.

The benefits to the customer given by this warranty are in addition to other rights and remedies of the Australian Consumer Law in relation to the goods or services to which this warranty relates.

This warranty is provided by:

Electus Distribution Address 46 Eastern Creek Drive, Eastern Creek NSW 2766 Ph. 1300 738 555