


0237-BLACK  
XC5253

1. LED Indicator
2. USB Type-C Charging Port
3. Power/ Bluetooth/ FM Mode
4. Play/ Pause
5. Volume -/ Previous Song/ Previous Channel
6. Volume +/ Next Song/ Next Channel

## Package Contents

- 1(One) Wireless Speaker 7.9in. x 4.96in. x 3.94in. (20cm x 12.6cm x 10cm)
- 1(One) USB Type-C Charging Cable 19.7in. (50cm)
- 1(One) Instruction Manual

## Power On/Off

**Press and hold the 'M' Button for 2 seconds to turn on or turn off the speaker.**

Note: Always power off the speaker when not in use.

## Pair Wireless speaker with your mobile device

1. Keep the distance between your wireless speaker and mobile phone (or other devices) within 10 metres.
2. Power on the wireless speaker.
3. Activate the Bluetooth function on your phone within range and select "Aiwa ASP-0237" from the list shown.
4. You will hear a beep sound when pairing is successful.

## Charging your Wireless Speaker

**⚠** For your safety, please always use appropriate 5V output charger/ Adapter to charge the product. **DO NOT USE** Quick Charging USB Adapter to charge the product, as it might cause damage.

1. Use the USB Type-C charging cable provided with this wireless speaker.
2. Connect the USB plug to a USB port on a computer or wall adapter, then connect the USB Type-C plug to USB Type-C charging port on the speaker to begin charging.
3. The LED Indicator will turn red while charging and will turn off once fully charged.

### NOTE:

- Use a standard USB adaptor for charging.
- Charge the unit if it has not been used for more than 6 months.



**⚠ CAUTION:** The USB Type-C charging cable included with this item is intended for use with this product. Only use the included USB Type-C charging cable to charge this product.

## Bluetooth Speaker Mode

Play/Pause: Short press the Play/Pause Button once.

Next Track: Short press the "+" Button

Previous Track: Short press the "-" Button

Volume Up: Long press the "+" Button

Volume Down: Long press the "-" Button

## FM Radio Mode

Note: Please plug in USB Type-C cable as FM antenna before switching to FM Radio Mode.

Switch to FM Radio Mode: Short press the "M" Button once.  
Short press the 'M' Button again to go back to Bluetooth mode.

Auto Scan: Long press the Play/Pause Button.

Next Channel: Short press the "+" Button

Previous Channel: Short press the "-" Button

Volume Up: Long press the "+" Button

Volume Down: Long press the "-" Button

Mute/Unmute: Short press the Play/Pause Button

## Reconnect Wireless speaker to your mobile device

When powered on, the wireless speaker will automatically connect with the last successfully paired device.

## True Wireless Stereo (TWS) Mode (Optional - needs two speakers)

1. Place both speakers close to each other and turn on both speakers.
2. If connected, disconnect from any Bluetooth device.
3. Press and hold 'Play/Pause' Button on any one speaker. An alert sounds.
4. In a few seconds, the two speakers will connect wirelessly to each other with another audio alert.
5. Now connect to 'Aiwa ASP-0237' on your Bluetooth mobile device. Once connected, you can play stereo audio on the two speakers.

### Note:

- To disconnect the speakers, Press and hold 'Play/Pause Button' on any one speaker. You will hear an alert indicating they are disconnected.
- TWS works only in Bluetooth mode, not in FM mode.

## Technical Specification

Driver Diameter: 52 mm

Impedance: 4 Ohms

Power Supply: Li-ion Battery 3.7V 1200 mAh

Playtime: 1.5-2 Hours

Charging Time: 1.5-2 Hours

Bluetooth Range: 10 metres

Bluetooth Version: 5.3

USB Type-C Charging Cable Included

USB Type-C Charging Cable Rating 5V/1A Max.

## FAQ

### ◆ If the Wireless speaker cannot be paired with your device, please try the following:

Ensure that your speaker is in pairing mode or reconnection mode.  
Ensure that Bluetooth search function of your mobile device is activated.

### ◆ If the Wireless speaker cannot be recharged:

If you use a power outlet, ensure that the power supply is connected securely and the outlet works. If you use a computer, ensure that it is connected and the USB port is powered.

### ⚠ Safety instructions for the lithium battery and charging the product

-The input voltage to the product is DC 5V 1A.

-In order to charge the product in safe manner and reliable conditions, please only adopt certified appropriate charger/ adapter for charging the product.

-Only charge the product at ambient temperatures between 10°C/ 50°F and 40°C/ 104°F.

-Do not expose to sunlight or throw into fire.

-Switch off the product after use.

-In extreme cases, abuse or misuse of Lithium battery pack can lead to explosion, heat generation, fire development or smoke development.

Batch:00155082024

Keep All Relevant Information For Future Reference

