



FLOW S01  
XC5262

## 2-IN-1 PORTABLE SPLIT SPEAKER




USER MANUAL

### PARAMETER

Model	S01	Input	Type-C 5V/1A
BT version	V5.3	F.R	85Hz~20KHz
BT range	≤18M (Open field)	Distortion	≤1%
Speaker	2*5W	Play time	5 - 15 Hrs
Battery	2400mAh	Full charge	About 3H

### BUTTON FUNCTIONS



### CONNECTION & PLAY

#### •BT wireless playback

1. The Blue light flashes after power on, and the speaker enters the Bluetooth mode;
2. Turn on the Bluetooth of the mobile phone, search for the Bluetooth name "S01" and click connect;
3. You will hear a beep when the Bluetooth connection is successful

#### •TWS connection and playback

1. Two new "S01" will be directly connected when they are turned on at the same time (with prompt tone);
2. Double-click the "" button to turn on/cancel TWS pairing;
3. Turn on the Bluetooth function on your mobile phone, then select the speaker name "S01" to connect. There is a prompt sound when connection is successful.
4. TWS can only be used in Bluetooth mode.

P5: When the two speakers are not connected and turned on at the same time, two Bluetooth names will be displayed, and two devices can be connected separately and used as independent speakers.

#### •AUX cable playback

Connect your own AUX cable to your device and the speaker to play music

#### •Micro SD card playback(up to 64G)

After inserting the SD card into the speaker, with a beep, the speaker will automatically read the card and play, and the blue light flashes (supports APE/FLAC/WAV/MP3 format playback).

Button	Operating	Function Description
	Short press	a. Power on b. Playback mode switching: BT, TF, AUX
	Long press	a. Press and hold for 2 seconds to power on/off b. Press and hold for 10 seconds to reset
	Double-click	Enable/Disable TWS
	Short press	Previous song
	Long press	Volume down
	Short press	Next song
	Long press	Volume up
	Short press	a. When music is playing: short press for play/pause function b. When a call is incoming: short press to connect the call c. During a call: short press to hang up the call
	Long press	a. Press and hold for 3 seconds to disconnect the Bluetooth connection, there is a prompt tone; b. In the state of an incoming call: press and hold for 2s to reject the call;
	Double-click	When the phone's Bluetooth is connected: Quickly double-tap to call back the last call from your phone

### SAFETY PRECAUTIONS

1. The equipment complies with the standard GB 4943.1-2022
2. This product cannot be taken, please keep it out of the reach of children to prevent accidents;
3. Do not place the speaker in a high temperature environment, including direct sunlight;
4. Do not place the speaker near fire sources or other overheated environments;
5. Do not place the speaker in a humid or humid place;
6. In addition to the provided charging cable, please do not try to use other methods to charge the speaker;
7. Do not disassemble the speaker, and prohibit any attempt to repair or modify the speaker;
8. Please pay attention to drops, impacts, scratches or other behaviors that affect the function of the speaker. If there is any damage, such as hot, high temperature deformation or corrosion, please stop using the product and equipment immediately and contact the merchant;
9. If the speaker produces abnormal odours, higher than normal temperature, and abnormal changes in colour or shape, please stop using the machine immediately and contact the merchant;
10. If the battery is incorrectly replaced, there is a risk of burning, and only the same type or equivalent type of battery can be used for replacement;
11. Using the speaker at high volume for a long time may cause damage to your hearing.

### OTHER

1. When the speaker has not been used for more than 3 months, the speaker needs to be charged before use;
2. When not in use for a long time, it is recommended to charge the speaker once every 3 months, which can more effectively protect the battery;
3. It is recommended to use the speaker after it is fully charged.

### POWER DESCRIPTION

1. Please use your own USB-C charging cable and charger that supports 5V/1A charging;
2. The red light is always on when charging, will turn off when fully charged;
3. When the voltage is too low, there will be a "beep" tone.

### WARRANTY INFORMATION

Our product is guaranteed to be free from manufacturing defects for a period of 12 Months.

If your product becomes defective during this period, Electus Distribution will repair, replace, or refund where a product is faulty; or not fit for intended purpose.

This warranty will not cover modified product; misuse or abuse of the product contrary to user instructions or packaging label; change of mind and normal wear and tear.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and failure does not amount to a major failure.

To claim warranty, please contact the place of purchase. You will need to show receipt or other proof of purchase. Additional information may be required to process your claim.

Any expenses relating to the return of your product to the store will normally have to be paid by you.

The benefits to the customer given by this warranty are in addition to other rights and remedies of the Australian Consumer Law in relation to the goods or services to which this warranty relates.

This warranty is provided by:

Electus Distribution  
Address 46 Eastern Creek Drive, Eastern Creek NSW 2766  
Ph. 1300 738 555