

digitech

4K Android Media Player

with Remote Control



Model:
XC6014

Instruction Manual

BOX CONTENTS

1 x 4K UHD Media Player
1 x Remote Control

1 x HDMI Cable
1 x Power Supply

BASIC OPERATIONS

Power On/ Off and Sleep

1. Connect the box to the TV with HDMI cable, connect box to the power adaptor, Connect mouse or other input devices with USB port.
2. After the device and cable connected, power LED will turn blue.
3. After the device and cable disconnected, Power LED turns off.
4. Under power on mode, press remote control's power button, and device will enter sleep mode.
5. Under sleep mode, device will wake up, when you press the remote control's power button.


Open applications

Use remote control's arrow keys to choose the wanted program, click OK button to open the selected program

Switch in the applications


Click "My Apps" to view recently used programs, click program icon to switch application arbitrarily

Close Applications

Click icon = * to view recently used programs, choose one of them by click and hold, drag it to blank area to close the application

*This function only operated in the condition of Mouse mode

Back To Home Screen

Click  icon to return to home screen

Click  icon * on remote control to return to home screen

Media Player Setup



1. Select 'Settings'



2. Select 'Network & Internet'



3. Turn on Wi-Fi



4. Select 'Available networks'



5. Choose your network



6. Enter the network password



7. The system will confirm successful connection to the network

Date and Time Setup



1. Go to 'Settings',
then select 'Device
Preferences'



2. Select 'Automatic date
& time' to set the date
and time automatically

Apps Setup



1. Select 'APPS' from the main menu, then choose the desired application



2. Logging into streaming services will be required to access the app

Media Files



1. Select 'File Explorer' to browse media files



2. Select 'Allow' to access files from internal storage, SD card, external hard drive, or USB stick

Media Files




1. Select 'Settings'



2. Select 'Device Preferences'



3. Select 'Reset'



4. Select 'Reset' again to confirm and complete the process

SPECIFICATIONS

CPU	Quad-core processor
Video Decoding	HEVC H.265
Video Output	4K Ultra HD (3840 × 2160)
3D Support	Yes
Wi-Fi	Built-in
Ethernet	Yes (RJ45 port)
Miracast	Built-in screen mirroring
Google Assistant	Supported

WARRANTY INFORMATION

Our product is guaranteed to be free from manufacturing defects for a period of 12 Months.

If your product becomes defective during this period, Electus Distribution will repair, replace, or refund where a product is faulty; or not fit for intended purpose.

This warranty will not cover modified product; misuse or abuse of the product contrary to user instructions or packaging label; change of mind and normal wear and tear.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and failure does not amount to a major failure.

To claim warranty, please contact the place of purchase. You will need to show receipt or other proof of purchase. Additional information may be required to process your claim.

Any expenses relating to the return of your product to the store will normally have to be paid by you.

The benefits to the customer given by this warranty are in addition to other rights and remedies of the Australian Consumer Law in relation to the goods or services to which this warranty relates.

This warranty is provided by:

Electus Distribution

Address 46 Eastern Creek Drive, Eastern Creek NSW 2766

Ph. 1300 738 555