

4L Smart Pet Feeder with 3MP Camera



Model:
LA4230



Please read and save all instructions to ensure safe and effective use of this product.

Instruction Manual

BEFORE FIRST USE

Prior to using your product, please read all the safety and operating instructions thoroughly. Please ensure you follow the steps below before using the product. We recommend you keep the original packaging for storing the product when not in use.

Please pay close attention to the section entitled Warnings & Safety Information. Find a safe and convenient place to keep this instruction manual for future reference.

Unpack the product but keep all packaging materials until you have made sure your new product is undamaged and in good working order. Ensure you have all accessories listed in this manual.

WARNINGS & SAFETY INFORMATION

WARNING: The manufacturer is not responsible for any potential injury from misuse

- Please place the device correctly; prevent the pet from tipping over the device. This device is only suitable for small and medium pets under 20kg.
- Please replace the desiccant in the storage lid regularly. No desiccant is needed.
- Please keep the food bucket dry and sealed, and check regularly to ensure food residue
- Do not drop all substances other than pet dry food into the grain bin. Otherwise, the device may be used abnormally or even cause pet safety problems.
- To prevent the pet from falling over the product, it is recommended to place the corner or against the wall.
- The product anti-battering line should be installed as concealed as possible to prevent the equipment from being damaged by the pet biting the wire.
- If children are using this device, be sure to use it under adult guidance.
- After installing the spare dry battery, you can manually operate the device to provide normal power supply during power failure.
- Regularly clean the food bucket and food bowl.
- This device is not recommended for young pets within three months.

BOX CONTENTS


1 x Adapter

1 x Cable

1 x User Manual

1 x Desiccant

PRODUCT OVERVIEW



NOTE: Battery use instructions: When the external power fails, the device will automatically enable the installed battery to power the device. (The device cannot charge the battery)

OPERATING GUIDE

The first use

1. Open the top cover of the feeder and remove the power cord adapter from the bucket.
2. Plug the power cord into the power connector on the rear of the main unit and connect the adapter to power.
3. Place the main unit in a horizontal position and the food bowl is installed at the corresponding position of the main unit.
4. Add pet dry food to the feeder bucket.
5. The desiccant is placed in the desiccant box by default. Please replace it regularly for long-term use (do not use cleaning)
6. The battery compartment can be installed with sections of No. 1 battery for manual feeding when there is no electricity (optional).
7. Bind the feeder to the Smart Life app to set up the feeding and planning of the pet.

The function description

- Feed button: Short press to eat one, long press for 5 seconds to restore the factory settings.
- Record button: Press and hold the “Record button” to record the sound to remind the pet to eat before feeding.
- Play button: Plays the recorded sound. power switch :turn ON/OFF feeder
- Battery Slot: Install 3 pos D batteries can supply power.

APP INSTALLATION




APP download and installation

Scan the QR code below to download the Smart Life app and complete the installation.




Registration


Open the installed smart life App and follow the prompts to register




Video Version Pet Feeder Configuration




Open the APP, click “add device” “Security& Sensor” “Smart Camera”, enter wifi password and confirm, connecting till “device added successfully”.



App Interface




1. Setting: set other functions
2. Signal: Signal quality
3. Horn: Real-time monitoring
4. DSD/HD: switch image quality
5. Full screen
6. Screenshot: take a picture from the video
7. Talk: 2 way voice intercom
8. Record: take record and save into the mobile phone
9. Photo album: store photos
10. Play: SD card video playback
11. Timed feeding: delivery food at regular intervals
12. Feeding: click to feed
13. Alarm: motion detection alarm on/off



CLEANING/MAINTENANCE

After the feeder has been used for a period of time, the bowl and the bucket should be cleaned with a cleaning agent to avoid the occurrence of bacteria that affect the health of the pet due to the long time left by the food residue.



1. The upper showed machine parts can be removed from the main feeder and cleaned with detergent and water.
2. Open the desiccant box in the top cover.
3. Grain barrel disassembled by turning the Grain drum separation switch.
4. Pull up to remove the food bowl.
5. After cleaning, it must be dried or air-dried before being assembled into a whole main feeder for use.

This feeder is suitable for dry foods smaller than 12 mm. Freeze-dried food is not available. Please keep the environment dry.

The feeder is not connected, what is the problem, what to do?

1. Check if the machine is normal: Check the status of the device indicator. After the power is turned on, the blue indicator light flashes. When the network is connected, it will be on. There will be a drop tone before the network is configured.
2. Check if the WiFi username and password are normal: Wi-Fi username and password cannot have special characters. It is recommended to use English letters + number signs.
3. Uninstall the software and reinstall the software, Please authorize the APP to obtain the location information and access the network permissions during the installation process.

Follow the above steps, and enter the correct wifi password. If you still have difficulties, please contact customer service.

When connecting the feeder, sometimes it can be connected normally, sometimes not, how to deal with it?

Check if the machine's food outlet is blocked. At this time, the blue indicator is always on.

Why does the feeding time differ by tens of seconds from the current time?

The parameters set on the APP will have an error of about 30 seconds depending on the timing of the network environment.

How to quickly reconnect after the machine is disconnected?

1. Exit the APP and re-enter, wait for the data update.
2. Switches from the feeding interface to the video interface and waits for the video to refresh.

Feeder requirements for network type?

The feeder must use a wifi signal that satisfies the wifi 802.11bgn protocol.

WARRANTY INFORMATION

Our product is guaranteed to be free from manufacturing defects for a period of 12 Months.

If your product becomes defective during this period, Electus Distribution will repair, replace, or refund where a product is faulty; or not fit for intended purpose.

This warranty will not cover modified product; misuse or abuse of the product contrary to user instructions or packaging label; change of mind and normal wear and tear.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law.

You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and failure does not amount to a major failure.

To claim warranty, please contact the place of purchase. You will need to show receipt or other proof of purchase. Additional information may be required to process your claim.

Any expenses relating to the return of your product to the store will normally have to be paid by you.

The benefits to the customer given by this warranty are in addition to other rights and remedies of the Australian Consumer Law in relation to the goods or services to which this warranty relates.

This warranty is provided by:

Electus Distribution

Address 46 Eastern Creek Drive, Eastern Creek NSW 2766

Ph. 1300 738 555