


Introduction:

Designed to be a direct replacement for your standard GPO fittings, combining two standard 240AC 10A mains (GPO) outlets with a built-in RCD to provide protection against electrical shock. In the event of a fault with the connected appliance or accident, such as a cut through the mains lead, the unit will provide complete isolation from mains. A test button, status indicator, and reset button allows you to check the RCD, which we recommend should be done each time before use.



Specifications:

CD Classified:	Type II
Rated Voltage:	230-240VAC
Rated Current:	20A max (Total)
Frequency:	50Hz
Rated Tripping Current:	30mA
Operating Speed:	<40mS Max.
L/Nin-L/Nout:	2KV
Endurance:	2000 Cycles Minute
RCD Contact Break:	Double Pole
Switch Contact Break:	Single Pole
Standards:	RCD Module-AS NZS 3190, Socket-AS NZS 3112
Minimum Back Box Depth:	35mm
Fixing Screws:	M3.0 x 25mm
Cable Capacity:	4x2.5mm ² , 2x4mm ² , 1X6mm ²
IP Rating:	IP30
Weight:	144g
Dimensions:	120(W) x 76(H) x 50(D)mm

Operation:

The RCD socket should be tested (as below) each time before use. Testing Procedure:

- 1) Remove appliance plugs from sockets.
- 2) If the red signal flag is not visible in the status window, press the dark green button (Reset).
- 3) The red flag should appear in the status window. If the red flag does not appear it may mean that there is no mains supply fed to the socket. If mains supply is being fed to the socket and the red flag does not appear, see 'Safety Notes' below.
- 4) Press the blue button (Test). The red flag should disappear. If the red flag remains visible, do not use. See 'Safety Notes' below.
- 5) Reset the device by pressing the dark green button (Reset). The red flag should reappear in the status window.

Safety Notes:

- 1) If the device does not operate in the way described in 'Test Procedure' above, do not use. It is likely that the RCD device is faulty and should be returned to the vendor from whom it was purchased.
- 2) No attempt should be made to repair the RCD socket. The units are sealed to prevent tampering and any damage to this seal will invalidate the guarantee.
- 3) This s.r.c.d. has been designed for storage and use between -10°C and +45°C, with an average value not exceeding +35°C measured over 24h period. And at an altitude of not greater than 2000m above sea level.

- 4) Care must be taken not to subject your s.r.c.d. to abnormal pollution by smoke, chemicals or flammable fumes, salt-laden spray, prolonged periods of high humidity, immersion, repeated dropping or other abnormal conditions.
- 5) Electricity is dangerous and an RCD must not be used as a substitute for normal precautionary measures. Always unplug from mains supply before any inspection or repair to equipment. Do not allow children to tamper with electrical devices.
- 6) Seek advice from the manufacturer, responsible vendor or a competent electrician if the s.r.c.d. repeatedly trips with an appliance connected or if it should fail to trip when tested in accordance with the instructions.
- 7) This device is intended for fixed-wiring installations only; it not legal for installations requiring double pole mains switching (caravans, portable power distribution boards etc).

Using the RCD Socket:

- 1) Insert the plug(s) of the appliance(s) you wish to use.
- 2) The RCD socket should remain set and the appliances should work normally. The red flag will remain visible in the status window. If the action of plugging in the appliance causes the device to trip (the red flag will disappear from the window), it is likely that there is a fault with the appliance. Consult a qualified electrician (see following note).

Note: The circuit to which the RCD socket is connected, may be protected by another backup RCD somewhere else in the circuit. In the event of a fault developing, the backup RCD may trip before the RCD socket.

Installation for RCD Instructions:

Switch off the mains supply and remove the appropriate fuse or switch off the appropriate circuit breaker before commencing installation. Ensure that no one else has access that would enable the supply to be inadvertently reconnected.

These accessories must only be installed by a competent person and in accordance with the current edition of the Australian/New Zealand Wiring Regulations (AS NZS 3000: Requirements for Electrical installations) and any applicable statutory regulations.

NOTE: IF YOU ARE IN ANY DOUBT ON HOW TO PROCEED, CONSULT A QUALIFIED ELECTRICIAN.

The RCD sockets can be installed in the same manner as a conventional socket into any moulded 2 gang surface box to AS/NZS IEC 60670 of suitable depth.

The RCD socket can either be used on a ring circuit, in which case there will be a pair of twin and earth cables entering the box, or on a spur, which will only have one twin and earth cable entering the box. All the individual insulated wires should have 12mm of insulation removed from the free ends.


In all cases the bare ends of the brown (Live) conductors should be secured firmly into the active terminal (marked A/LINE), and the bare ends of the blue (Neutral) conductors should be secured firmly into the neutral terminal (marked N/LINE). The bare earth wires should be sleeved with green and yellow PVC sleeving up to 12mm, from the free ends and the bare ends secured into the earth terminal (marked E).

Connect a short length of wire from the accessory earth terminal to the earth terminal in the wall box. If the earth wire is bare it should be sheathed with a length of green/yellow sleeving.

The socket is then gently pushed into the box ensuring the wires are formed to lie in the box out of the way of the socket. The socket is retained in the box by means of the two 3.0mm screws provided. These are passed through the mounting holes of the socket and screwed into the box lugs.

Tighten sufficiently to hold the socket against the wall (or the front of a moulded box), ensuring the screws are not over-tightened.

⚠ WARNING! Please note that RCD sockets should be dis-connected from the circuits prior to carrying out any insulation tests.



Distributed by:
TechBrands by Electus Distribution Pty. Ltd.
320 Victoria Rd, Rydalmere
NSW 2116 Australia

Ph: 1300 738 555
Int'l: +61 2 8832 3200
Fax: 1300 738 500

www.techbrands.com

Made in China