

STOPWATCH

USER'S INSTRUCTION

FEATURES

- Time / Calendar display
- Hour (12/24-hour format), minute, second, month, date and day
- Stopwatch: 1/100 second for 30 minutes, 1 second up to 24 hours



FUNCTION KEYS

- A. MODE button:**
- Switch among normal time mode, stopwatch mode, alarm time setting mode and normal time setting mode.
- B. START/STOP button:**
- Toggle between normal time and month/date display.
- C. SPLIT/RESET button:**
- Toggle between normal time and alarm time display.

DISPLAY SYMBOLS

Normal Time Mode

1. Day of the week
2. Hour
3. Minute
4. Second



Alarm Time Mode


1. Alarm time
2. Alarm icon




STOPWATCH MODE

In normal time mode, press **A** once to activate this mode. Press **C** to reset the stopwatch to "0:00:00" before using the stopwatch.


1. Accumulate elapsed time measurement: B-B-B-B-C



2. Split time measurement: B-C-C-B-C



3. Measurement between two competitors: B-C-B-C-C




Note:

1. Press **A** to return to the normal time mode.
2. 1/100 second stopwatch for 30 minutes, and 1 second stopwatch from 31st minutes up to 24 hours.

TIME / CALENDAR SETTING

1. In normal time mode, press **A** three times to activate time setting mode.
2. Press **C** to select the setting items. The sequence will be: Second > Minute > Hour > Date > Month > Day.
3. Press **B** to increase the setting value and change 12/24 hour format when setting the hour.
4. Press **A** to return to normal time mode.




Note:

1. Press **B** to add one minute when the second is more than or equal to 30 and reset it to 00 when the value is less than 30.

ALARM TIME SETTING

1. In normal time mode, press **A** twice to activate this mode.
2. Press **B** to change the hour value.
3. Press **C** to select the minute and press **B** to change the minute value.
4. Press **A** to return to normal time mode.




Note:

1. To turn the alarm ON/OFF, press **B** and **C** at the same time.
2. The alarm will turn on automatically once you set the alarm time.
3. When the alarm is on:
 - (1) It will last one minute without pressing any button then not sound again until the next day.
 - (2) When the alarm is sounding, press **B** to activate the snooze function and the alarm will start again after 5 minutes. It will sound up to one minute then not sound again until the next day.
 - (3) Press **C** to stop the alarm.

HOURLY CHIME SETTING

1. In normal time mode, press and hold **C** with alarm time displayed.
2. Press **A** at the same time until all days of the week appear / disappear.



BATTERY REPLACEMENT

When the LCD becomes dim, replace with a new LR44 battery at once.



WARNING – KEEP BUTTON BATTERIES OUT OF REACH OF CHILDREN

- If swallowed a lithium button battery may lead to serious or fatal injury in as little as 2 hours, due to chemical burns and potential perforation of the oesophagus
- All button batteries must be kept away from children regardless if they are new or used.
- If you suspect your child has swallowed or inserted a button battery immediately call the 24-hour Poisons Information Centre on 13 11 26 (Australia) or 0800 764 766 (New Zealand) for fast, expert advice.
- If your child is having difficulty breathing contact 000 (Australia) or 111 (New Zealand).
- Dispose of used button batteries immediately and safely out of the reach of children. A battery can still be dangerous even when it can no longer operate the device.
- As soon as you have finished using a button battery, put sticky tape around both sides of it. This will make it harder for children to swallow the button battery and avoid the risk of the battery catching fire.
- Immediately dispose of button batteries immediately out of reach of children, or recycle using a child resistant container and take used cells to your local battery collection centre.

Distributed by:
Electus Distribution Pty Ltd
46 Eastern Creek Dr,
Eastern Creek NSW 2766
Australia
Ph 1300 738 555

www.electusdistribution.com.au