



MMA010

Inflatable Stand Up Paddle Board

INSTRUCTION MANUAL

GENERAL INFORMATION & SAFETY INSTRUCTIONS

Paddle sports can be dangerous and physically demanding. Users of this product should understand that participating in stand up paddling can result in serious injury or death. Observe all applicable watercraft laws, and use common sense Safety Check list

- Always paddle with others.
- Always wear a leash attaching you to the board.
- Wear an approved personal flotation device
- Always wear protective clothing.
- Always paddle in safe conditions.
- Be aware of changing weather conditions.
- Avoid paddling in off shore wind or windy conditions.
- Do not exceed your paddling ability; be aware of your limitations.
- DO NOT use alcohol or mind altering drugs prior to or while using this product.


Attention

- Wear an approved personal flotation device at all times.
- Never allow minors to use this board without adult supervision.
- Never use this product in poor lighting, after sunset or before sunrise.
- Always check local laws and regulations before using this product.
- Be aware of how current and tide affect you, your board and your location.
- Learn in calm, shallow water at first.
- Exercise caution when using this product in warmer conditions, as hot air temperatures can cause pressure changes in the board that can damage the paddle board.
- The stainless steel rings on the stern of the boat are only for the lines. Do not pull or tow people or vessels with the steel anchor rings or board handles.
- After use, rinse with fresh water and allow to dry completely. It is important to allow the board to dry completely before storing it for an extended period of time to prevent mold.

WARNING: The manufacturer is not responsible for any potential injury from misuse

USAGE INSTRUCTION

- Assume a comfortable stance with your feet positioned roughly shoulder width apart. Knees slightly bent in a relaxed upright stance, shoulders back, looking straight ahead.
- Paddle grip. Place your top hand on end of handle and your bottom hand approximately 24" down shaft of paddle. Paddle in a comfortable forward motion, with arms slightly bent.
- To turn left concentrate paddling on the right hand side of the board to turn right concentrate paddling on the left hand side of the board.



Correct Paddle Position

BOARD INFLATION

Follow the instructions below for valve operation and correct inflation and deflation procedures.



A. Valve Operation:
To close off the valve for inflation, make sure that the center valve pin is in the "up" position. If it is in the "down" position, press down on the valve pin until it pops up.



B. To open the valve for deflation, press down on the valve pin to it locks down. Be careful of any sand or debris around the valve area when deflating as small particles could become airborne with the release of air pressure!



C. Always lock the valve cover over the valve stem when in use. This will prevent accidental air release and entrance of any particles into the air chambers.

Board Inflation Steps

1. Make sure that the valve is in the closed position (valve pin up)
2. Make sure the pump hose is connected to the “inflate” outlet
3. Connect the pump nozzle into the valve receptacle.
4. Start pumping air into the board by sliding the pump piston up and down.

NOTE: If the pump piston starts to squeak, apply some spray silicone on the piston shaft.



Board Deflation Steps

1. Clear any water or debris out of the valve areas.
2. Slowly press down on the valve stem to start letting air out of the board. There will be an initial burst of air, but that will slow down very quickly. Once the air flow has slowed down, press the valve stem all the way down and turn it clockwise to lock it into the “open” position.

Inflation Tip & Precautions

- The board can be inflated either with our hand pump or an electric pump. The electric pump can inflate the board to a moderate pressure and save time with about 90% of the required air volume. You will need to use your hand pump to inflate the chambers to the correct pressure.
- Do not use an air compressor. Damage to your board caused by over inflation from an air compressor is not covered by your warranty.
- After 2 or 3 days there may be a small decrease of pressure due to temperature change. If so, add a few pumps of air.
- Before undertaking a long paddle, inflate the board for a full 24 hours to be sure the board is airtight. If you are seeing a consistent decrease in air pressure, follow the instructions for leak detection in the board repair section of this manual.

- Do not over-inflate the board. A max pressure of 10 - 14 PSI is adequate. The easiest gauge of a good working pressure is to have the chambers inflated to a firm pressure when you press on them.
- Do not pump to a high pressure and let the board sit out in the sun. If the board is going to be in a warm environment, slightly under-inflate the board and allow the heat from the
- sun to increase the internal pressure. When paddling, the colder temperature of the water may cause a slight loss in chamber pressure. It is a good idea to carry a pump with you so that you can add some air to the chambers if necessary.

CENTER FIN INSTALLATION



1. Slide fin base into fin box.



2. Slide fin all the way to back of the fin box. Put screw inside the fin box first for some type of fins.



3. Insert fin retention pin through slot.



4. Correct fin installation

BOARD CARE & STORAGE

We have chosen high quality PVC to provide superior protection from ultraviolet light.

However, to ensure extra years of flexibility and bright colors, avoid storing the board where it will be exposed to weather or in direct sunlight. Please review the following list for storage and board care tips.

- Before storing, hose off the board and let it dry completely to prevent mildew buildup.
- Do not use harsh chemicals for cleaning. Most dirt can be removed with a mild soap and fresh water.
- You may store the board inflated or deflated. If you deflate the board, we recommend that you store it in the protective bag that came with the board
- If storing the board outdoors, raise it up off the ground and cover it with a tarp to prevent exposure to the elements
- We do not recommend hanging the board.
- Do not store in extreme conditions (i.e. above 60°C or below -20°C)
- Store in a clean, dry place.

LEAK DETECTION & REPAIR

About PVC

Your new stand up paddleboard is made from a durable PVC. If a tear or puncture does occur, PVC is very easy to repair. Repairs are easily done with your included patch kit. Read the following paragraphs for leak detection and repair tips.

Air Leak Detection

If you are losing air pressure, not caused by colder temperatures, check the board for leaks, starting with the valves. A leaking valve is rare, but if you do find a leak we can send you a replacement valve. To locate a leak, we recommend mixing soap and water in a spray bottle. Spray around the valve. If you see bubbles forming, check your valve seating and base and be sure the valve insert is screwed tight. If you continue to have problems it's probably time to order a new valve. Replacement of the whole valve can be done with a simple tool that comes with the replacement valve.

If the board is losing air and all the valves are good, you probably have a small puncture. Small punctures can be repaired easily and permanently. Spray around the inside and outside of the board until air bubbles become visible and mark the position of the leak. If you do not find air bubbles, inflate the board to maximum air pressure and try to listen to find the leak. If you can narrow the area down, return with a spray bottle to identify the source of the leak.

Punctures less than 3mm size can be repaired simply without a patch. Deflate your board, then clean and dry the area to be repaired. Apply a small drop of glue to cover the puncture, and let dry 12 hours.

Repairs

Your board comes with a repair kit as standard equipment. Cut a piece of repair material large enough to overlap the damaged area by approximately 1cm, and round off the edges. Apply glue to the under side of the patch and around the area to be repaired. Too much glue will interfere with a proper repair. Allow adhesive to become tacky for 2-4 minutes, and then place patch on the damaged area. Use a weight to apply 2-4kg of pressure for 12 hours. After patch has dried, apply glue around the edges for a complete seal (dry for 4 hours).

WARRANTY INFORMATION

Our product is guaranteed to be free from manufacturing defects for a period of 12 Months.

If your product becomes defective during this period, Electus Distribution will repair, replace, or refund where a product is faulty; or not fit for intended purpose.

This warranty will not cover modified product; misuse or abuse of the product contrary to user instructions or packaging label; change of mind and normal wear and tear.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and failure does not amount to a major failure.

To claim warranty, please contact the place of purchase. You will need to show receipt or other proof of purchase. Additional information may be required to process your claim.

Any expenses relating to the return of your product to the store will normally have to be paid by you.

The benefits to the customer given by this warranty are in addition to other rights and remedies of the Australian Consumer Law in relation to the goods or services to which this warranty relates.

This warranty is provided by:

Electus Distribution

Address 46 Eastern Creek Drive, Eastern Creek NSW 2766

Ph. 1300 738 555