## Smartwatch operation instructions

**Dialing:** When the smartwatch is connected with the smartphone, the smartwatch will be a Bluetooth headset(with microphone and speaker) of your smartphone to make a phone call.

**Phonebook:** After the Smartwatch is connected to the APP successfully, you can add 50 frequently-used contacts in the APP. After the contact is successfully added, the Smartwatch phonebook will be displayed and you can click on contacts to make calls.

**Call record:** keep a record of calls made by the Smartwatch.

**Information:** keep the information pushed by the mobile phone: you can view the last 8 pushed messages.

**Sports mode:**
1. Record running distance and calorie consumption in running mode
2. Record calorie consumption in skipping mode
3. Riding distance and calorie consumption in riding mode
4. Calorie consumption in swimming mode
5. Climbing mode Walking records and calorie consumption

**Pedometer record:** display the step count, completion status, walking distance and calories of the day.

**Sleep detection:** Wear the Smartwatch when sleeping, the Smartwatch will record the length of sleep, deep sleep,light sleep and awake time. You can view the details of your sleep data on the APP side, and you can also set the sleep detection time range.

**Sedentary reminder:** The period of the sedentary reminder and the effective time range of the sedentary reminder, the sedentary switch needs tobe set in the APP-side.

**Remote Shutter:** Needs to be connected to the APP. Click this icon on the smartphone to open the camera app on the phone. Shake the smartwatch to take a picture on your phone. Close the remote camera on the smartwatch to exit the camera app on the phone.

**Flashlight:** Turn on the flash light function, the Smartwatch screen will be bright.

**Find mobile phone:** When the APP is connected, enter the function of finding mobile phone, long press the icon, the phone will send out a ringtone reminder.

**Device information:** display the MAC serial number and version number of the device.

**Brightness adjustment:** Adjust the screen brightness. You can choose from 5 levels of brightness.

**Alarm:** When connected to APP, you can add an alarm to the alarm reminder on the APP and synchronise to the smartwatch. You can add up to 5 alarms.

**Bluetooth music:** When the smartwatch is connected with the smartphone, the smartwatch will be a Bluetooth speaker of your smartphone to play music.

---

# aiwa
Japan (since)

**ACTIVE SMARTWA**

ASA-0025-BLUE / ASA-0025

## Instruction Manual

---

## Product Overview



1. MENU Button:
Press: Open menu / Back to main page.
Turn: Zoom in & out of menu / Select watch face.

2. ON / OFF / APP Shortcut

3. Wireless Charging Area

## Package Contents

**Includes:**
1(One) Smart Watch
1(One) Wireless Charging Cable
1(One) Instruction Manual

## Specifications

System Requirements: iOS 9.0 and above, Android 5.0 and above
Battery Capacity: 120 mAh
Control Method: Touchscreen, Push/Turn Crown
LCD Screen: 1.83 inch HD screen
Screen Resolution: 240 x 286

Wireless Charging Cable Included

## Power On/Off

**Power On**
Press and hold down the ON/OFF Button of smartwatch for 3 seconds .

**Power Off**
Press and hold down the ON/OFF Button of smartwatch for 4 seconds and the watch will turn off.

## Connecting to a Smartphone

The Bluetooth pairing name is "ASA-0025". Before connecting to the HiWatch APP, in the smartphone's Bluetooth setting, search and connect with the smartwatch.
Then the smartwatch will become a Bluetooth speaker of your smartphone to play music or make calls. After that, start the HiWatch APP, in the Equipment/Device tab, select "Binding/Go bind" to connect the smartwatch.
When the APP is connected to the smartwatch successfully, the clock on the smartwatch will synchronize with the Smartphone.

## APP download method

Android download method: Search "Hiwatch Ultra" in the Android application market to download the application or scan the QR code to download

IOS download method: Scan the QR code to download the APP application

## Preparation before use

Charge the smartwatch before first use and whenever the battery becomes weak.

This smartwatch has wireless charging. To charge, connect the Type-A end of the charging cable to a suitable USB adaptor. Hold the charging pad to the rear of the smartwatch (wireless charging area) to start charging.

## Function

**Message reminder:** Choose what messages are pushed to the smartwatch (for example, incoming calls). Requires notificaiton permission set for each app.

**Alarm reminder:** Set a reminder alarm. Once set, it will be synchronised to the smartwatch and the smartwatch will have a vibration reminder at that time. Even if the smartwatch is disconnected from the APP later, it will still produce the reminder at the set time.

**Sedentary reminder:** Switch on the sedentary function and set the reminder duration and time range of sedentary. After the setting is successful, it will be synchronized to the Smartwatch, and the wristband will send a vibration reminder at the time point of sedentary setting.

**Remote self-timer:** Using the APP, start taking pictures from the smartwatch or enter the remote camera interface from the APP. Shake the smartwatch one time to take photos automatically after 3 seconds. Please allow APP to access the album to save the selfie pictures.

**Sleep detection:** When connected to the Smartwatch, you can set the detection time of the Smartwatch sleep detection.

**Vibration:** Turn on / off the vibration reminder function of the Smartwatch. After closing, your Smartwatch will not have the vibration function.

**Language setting:** It can be set according to the language supported by the Smartwatch. After the setting is completed, the Smartwatch will automatically switch to the language you set.

**Wearing mode:** Left-Smartwatch / right-Smartwatch wearing mode you can match pedometer and other data algorithms according to which hand you wear the smartwatch.

**Synchronize system time:** Manually synchronize the time of the phone to the Smartwatch.

**Restore factory:** Let your device reset and clear data, such as step count or sleep tim

**Raise your Smartwatch to brighten the screen:** When this function is turned or if you raise your wrist and turn the screen towards you, the screen turns on. If you lower your wrist, the screen turns off.

## Smartwatch maintenance

• Do not scratch the sensor, protect it from damage.
• Wipe the surface of the Smartwatch with a damp cloth and use mild soapy water to remove oil or dust.
• Do not expose the Smartwatch to the environment with strong chemicals, such as gasoline, cleaning solvents, propanol, alcohol or insect repellent. The chemicals will damage the sealability of the Smartwatch and the surface of the casing.
• Prevent your Smartwatch from being subjected to strong impact and extreme high temperature exposure.
• When the lens and casing are intact, it is waterproof. Violent disassembly will affect the waterproofness.
• Do not use or store exposed to direct sunlight or high temperatures.
• Do not use near stovetops, heaters or similar devices.
• This product is not a toy. Not suitable for young children.